




CROSELEY MODELS 02CP, 02CQ — CHASSIS MODEL No. 70

SOCKET VOLTAGES MEASURED AT 117.5 V. LINE (BETWEEN SOCKET PIN AND CHASSIS) WITH 1000 OHM PER VOLT, 500 V. RANGE VOLTMETER (D. C.)



TUBE	FUNCTION	1	2	3	4	5	6	7	8
		PIN NUMBER							
6SK7	R. F. Amplifier	Grd.	Grd.	Grd.	0	Grd.	74	6.3 A. C.	180
6S7	Converter	Grd.	Grd.	180	74	0	{0.5 W. } {4.0 B. C.}	6.3 A. C.	0
6SQ7	1st I. F. Amplifier	Grd.	Grd.	Grd.	0	Grd.	74	6.3 A. C.	180
6J5	Phase Inverter	Grd.	Grd.	180	0	0	75	6.3 A. C.	40
6AC5	P. P. A. F. Drivers	Grd.	Grd.	180	0	0	J. B.	6.3 A. C.	6.5
6AC5	P. P. A. F. Drivers	Grd.	Grd.	304	0	0	J. B.	6.3 A. C.	310
5Y3	Rectifier	N. C.	Grd.	310	J. B.	6.5	J. B.	308 A. C.	J. B.
				J. B.		308 A. C.		310	

MAX. POWER OUTPUT 12.0 WATTS
 POWER CONSUMPTION 90 WATTS
 DROP ACROSS SPEAKER FIELD 120 VOLTS
 N. C.—No Connection



J. B.—Junction Block

CROSLY MODELS 02CP, 02CQ — CHASSIS MODEL No. 70

THE AUTOMATIC RECORD CHANGER

This record changer will automatically play a series of twelve 10" or ten 12" records of the standard 78 R. P. M. type. The records must be all one size when loading, and may consist of less records than listed above. Records with or without a starting groove will operate the changer satisfactorily and the inside stopping groove may be a spiral or an eccentric. This means that any type of record, regardless of make, will operate the automatic mechanism. Records of any size up to 12" may be played manually.

The records are supported for automatic operation in two points, in the center by the center post, and on the edge by the record holder post.

Alignment Sequence	Dummy Antenna	Frequency Setting	Input Connection to Receiver	Band Switch	Tuning Cond. Setting	Trimmer Adjusted	Remarks
1.	.02 MF.	455 Kc.	Stator lug Rear section of Gang Cond.	B. C.	Fully open	2nd I-F (2) 1st I-F (2)	Adjust for Maximum. Adjust for Maximum.
2.	.0002 MF.	1630 Kc.	Ant. Terminal	B. C.	Fully open	B. C. "OSC" Trimmer	Adjust for peak; gang does not have to tune thru signal. Loop must be connected.
3.	.0002 MF.	600 Kc.	Ant. Terminal	B. C.	Approx. 60 on dial	B. C. "OSC" Series Trimmer	Adjust for maximum output while rocking gang thru signal.
4.	Repeat Step No. 2 to check possible shift due to series adjustment.						
5.	.0002 MF.	1400 Kc.	Ant. Terminal	B. C.	Approx. 140 on dial	B. C. "ANT" Trimmer B. C. "R-F" Trimmer	Adjust for maximum output do not touch B. C. Osc. Trimmer. Adjust for maximum output.
6.	400 ohm (carbon)	5.3 Mc.	Ant. Terminal	P. Ice	Fully open	Pol "OSC"	Adjust for peak; gang does not have to tune thru signal.
7.	400 ohm (carbon)	5.0 Mc.	Ant. Terminal	Police	Approx. 5.0	Pol "ANT" Trimmer	Adjust for maximum output.
8.	400 ohm (carbon)	18.3 Mc.	Ant. Terminal	S. W.	Fully open	S. W. "OSC"	Adjust for peak. Gang does not have to tune thru signal.
9.	400 ohm (carbon)	18.0 Mc.	Ant. Terminal	S. W.	Approx. 18	S. W. "ANT" Trimmer	Adjust for maximum output while rocking gang thru signal.
10.	Repeat the above alignment procedure for more accurate adjustments. Always keep signal generator output as low as possible to prevent action of the A. V. C. circuit.						

When aligning the shortwave bands "OSC" trimmers care must be exercised to see that the circuits are aligned on the correct frequency and not on the image which is approximately 910 kilocycles less as indicated on the Receiver dial. To check, increase generator output, tune-in the generator frequency and then tune-in the image frequency which should be weaker than the fundamental and come in approximately 910 kilocycles lower on the Receiver dial than the fundamental. If image cannot be tuned-in, the "OSC" trimmer is adjusted to the wrong peak. (Correct peak is the second peak on trimmer from the closed position).

SETTING THE PUSH BUTTONS

The six station selector push buttons are set up by means of two adjusting screws per button. These adjusting screws are made accessible by removing the station selector push button escutcheon. Pry off carefully being careful not to scratch the main escutcheon.

Select the call letter tabs of your six favorite broadcast stations from the station call letter sheets supplied. Place the call letter tabs in the window above that push button which is to be adjusted for that station

