



# Model 39-40, Code 121



Philco Radio & Television Corp.

# PHILCO

## Model 39-40, Code 121



METHOD OF INSTALLING DRIVE CORDS ON TUNING CONDENSER DRUM


Operations	SIGNAL GENERATOR			RECEIVER		
	Output Connections to Receiver	Dummy Antenna (Note A)	Dial Setting	Dial Setting	Control Setting	Adjust Compensators to Max. Reading
1	6A7	.1 mf	470 KC.	580 KC.	Vol. Max. Range Switch Broadcast	26B, 26A, 23B, 23A
2	Ant. Ter.	150 mmf	1550 KC.	1550 KC.	"	15, 7B, 7A
3	Ant. Ter.	150 mmf	580 KC.	580 KC.	"	17
4	Ant. Ter.	150 mmf	1550 KC.	1550 KC.	"	15
5	Ant. Ter.	400 ohms	18.0 MC.	18.0 MC.	Range Switch S. W.	15A, 12, 5

**NOTE A**—The "Dummy Antenna" consists of a condenser connected in series with the signal generator output lead (high side). Use the capacity, as specified in each step of the above procedure.


**NOTE B**—Dial Calibration. In order to adjust the receiver correctly, the dial must be aligned to track properly with the tuning condenser. To adjust

the dial, proceed as follows: With the tuning condenser closed (maximum capacity), set the dial pointer on the extreme left index line at the low frequency end of the broadcast scale. The arrangement of the drive cable is shown on page 3.

**NOTE C**—Compensators (7A) and (7B) are located on top of the tuning condenser. Compensator (7A) is the first one from the tuning drum side.



ELECTRIC AUTOMATIC PUSH BUTTON UNIT



PART LOCATIONS UNDERSIDE OF CHASSIS MODEL 39-40

# Setting Push-Buttons on Models: --

39-25 39-30 39-31 39-35 39-40 39-45

Circuits	Frequency Range
1 and 2	540 to 1030 kilocycles
3 and 4	670 to 1160 kilocycles
5 and 6	900 to 1470 kilocycles
7 and 8	1170 to 1600 kilocycles

(C) Turn the receiver Tuning Range Selector to position two ("Manual Tuning") and tune the receiver to the station to be set on the first button.

(D) Plug the output leads of the Station Setter into the "High" and "Gnd" jacks, and turn the output controls to maximum. Turn the modulation control to "Modulation Off." Connect the output lead of the Station Setter to the "ANT" and "GND" terminals of the receiver and tune to the frequency of the station being received. As the indicator is slowly tuned through the frequency of the station there will be two points at which a high pitched swish will be heard, one above and one below the frequency of the station. When the indicator is on the frequency of the station, minimum high pitched swish will be heard.

(E) Set the modulation control of the Station Setter for "Modulation On." The modulated signal of the Station Setter will then be heard through the receiver.

(F) Turn the receiver Tuning Range Selector to position one (Automatic Tuning) and push in the first button. Using the Part No. 45-2610 Insulated Screw Driver, turn the number 1 "OSC" screw until the modulated signal of the Station Setter is tuned in to maximum volume. Then adjust the number 1 "ANT" screw for maximum signal.

(G) Remove the output lead of the Philco Station Setter from the "ANT" terminal of the receiver and turn its indicator off the frequency of the station. The program of the desired station will then be heard on the receiver.

(H) With the volume of the receiver low, slowly turn the number 1 "OSC" back and forth until maximum output is received. Repeat the same procedure for the number 1 "ANT" screw.

After setting up the first station, the same procedure given under (C) to (H) is used for the other stations.