



RCA Victor

MODEL U-50

CHASSIS No. RC-414C

Steps	Connect the high side of test-osc. to—	Tune test-osc. to—	Turn radio dial to—	Adjust the following for max. peak output
1	6K7 I-F grid cap. in series with .01 mfd.	455 kc	"A" Band quiet point between 550-750 kc	L10 and L11 (2nd I.F. trans.)
2	Tuning condenser stator (osc.) in series with .01 mfd. **	455 kc	600 kc (33°)	L8 and L9 (1st I.F. trans.)
3	Antenna lead in series with 200 mmfd.	600 kc	1,500 kc (152.4°)	L7†
4		1,500 kc	"A" Band	C2 (ant.) C8 (osc.)
5	Repeat steps 3 and 4			
6	Antenna lead in series with 400 ohms	20 mc	20 mc (155.4°)	C5 (osc.) * C26 (ant.)
7		6 mc	6 mc (149°)	C6 (osc.) * C27 (ant.)
8	Antenna lead in series with 200 mmfd.	1,500 kc	1,500 kc (152.4°)	C8 (osc.)

* Use minimum capacity peak if two peaks can be obtained.

† Rock gang condenser slightly while adjusting L7.

** Make test-oscillator connection to lug on tuning condenser stator (oscillator section) in series with .01 mfd. condenser.

Note.—Oscillator tracks 455 kc above signal on all bands.

Cathode-Ray Alignment is the preferable method. Connections for the oscillograph are shown in the chassis drawing.

Output Meter Alignment.—If this method is used, connect the meter across the voice coil, and turn the receiver volume control to maximum.

Test-Oscillator.—For all alignment operations, connect the low side of the test-oscillator to the receiver chassis, and keep the output as low as possible to avoid a-v-c action.

Calibration Scale On Indicator-Drive-Cord Drum.—In most cases it will not be necessary to remove the chassis from the dial scale for alignment, allowing the dial scale to be used for calibration. However, if alignment is made with the receiver chassis removed, the calibration scale attached to the rear of the drum which is mounted on the front shaft of the gang condenser must be used. The setting of the gang condenser is read on this scale, which is calibrated in degrees. The correct setting of the gang in degrees, for each alignment frequency, is given in the alignment table.

As the first step in r-f alignment, check the position of the drum. The 135° mark on the drum scale must be vertical, and directly under the center of the gang-condenser shaft when the plates are fully meshed. The drum is held in place by one set-screw, which must be securely tightened when the drum is in the correct position.

Pointer for Calibration Scale.—Improvise a pointer for the calibration scale by fastening a piece of wire to the gang-condenser frame, and bend the wire so that it points to the 0° mark on the calibration scale when the plates are fully meshed.

Dial-Indicator Adjustment.—After fastening the chassis in the cabinet, attach the dial indicator to the drive cable with indicator at the 530 kc mark, and gang condenser fully meshed. The indicator has a spring clip for attachment to the cable.

