



Underwriters approved models have a common negative.
Non-underwriters approved models do not have parts 21 and 32, and all connections to the common negative are grounded directly to the chassis.