



Precautionary Lead Dress.—

1. The lead from the 8Q5 plate to output transformer should be dressed under clip and away from audio input leads.
2. Keep AVC lead connecting C1 away from the 1A7GT plate.
3. Keep blue plate leads coming from IF transformers short and close to the chassis.
4. All filament wires should be dressed close to chassis.

