



Alignment Procedure

Allied Radio Knight Models

5A-150
5A-152
5A-154
5A-163

Steps	Connect output of oscillator to	Tune osc. to	Tune radio dial to	Adjust the following for max. peak output
1.	Tuning condenser stator (ant.) in series with .01 mfd.	455	Quiet point at high frequency end of dial.	1st and 2nd I. F. Transformers
2.	Antenna term. of Ant. loop in series with 100 mmf.	1720	Full clockwise (out of mesh)	Osc. trimmer
3.	Antenna term. of Ant. loop in series 100 mmf.	1500	1500	Ant. trimmer

Output meter is connected across voice coil. Receiver volume is turned to maximum.