



I.F. 455 KC.

M49B

25Z6G +105V. DC

| RESISTORS | | |
|------------|----------|-------------------------|
| Ref. No. | Part No. | Description |
| R59 | 17-4391 | 15,000 ohms 1/2 watt |
| R27 | 17-4788 | 2,000,000 ohms 1/2 watt |
| R106 | 17-14171 | 50,000 ohms 1/2 watt |
| R109 | 17-14174 | 500,000 ohms 1/2 watt |
| R-113 | 17-14178 | 250,000 ohms 1/2 watt |
| R149 | 17-14211 | 150 ohms 1/2 watt |
| R150 | 17-14212 | 5,000,000 ohms 1/2 watt |
| R154 | 17-14214 | 1,500,000 ohms 1/2 watt |
| CONDENSERS | | |
| Ref. No. | Part No. | Description |
| C7 | 17-2064 | .0001 mfd. 600 volt |
| C104 | 17-4206 | .01 mfd. 200 volt |
| C48 | 17-4207 | .00025 mfd. 600 volt |
| C9 | 17-4292 | .001 mfd. 600 volt |
| C5 | 17-14015 | .05 mfd. 200 volt |
| C112 | 17-14139 | .05 mfd. 400 volt |
| C172 A & B | 17-14239 | 20-20 mfd. 150 volt |
| C174 | 17-14248 | .2 mfd. 400 volt |
| C1-C2 | 17-19900 | Tuning Condenser |

| COILS and TRANSFORMERS | | |
|------------------------|-------------------------------|--|
| Part No. | Description | |
| T2 | 00-15979 Oscillator Coil | |
| T-5 | 00-15980 Output Transformer | |
| T3 | 00-16060 1st I.F. Transformer | |
| T4 | 00-16061 2nd I.F. Transformer | |
| T1 | 00-16083 Antenna Coil | |

| | |
|-----------|-------------------------------|
| 17-15791E | Line cord and plug |
| 29-15905 | Cabinet (58A Ivory) |
| 32-15907 | Chassis bottom cover |
| 29-15909 | Cabinet (58-Black) |
| 32-15915 | Tuning shaft bracket |
| 29-15916 | Cabinet back cover |
| 17-15926A | Volume control switch |
| 29-15929 | Knob (wood-walnut finish) |
| 29-15937 | Knob (walnut bakelite) |
| 23-15958 | Tuning Shaft |
| 17-15973 | Dial light socket and clip |
| 81-15974 | Dial glass (black background) |
| 17-15983 | Speaker (5" diameter) |
| 17-15989 | Speaker (6" diameter) |
| 81-16015 | Dial glass (brown background) |
| 27-16020 | Cabinet (Model 88) |
| 17-16021 | Phono pickup and arm |
| 17-16022 | Phono turntable and motor |
| 29-16024 | Knob (Ivory bakelite) |
| 17-16065 | Radio-Phono switch |
| 29-16068 | Knob (Radio-Phono switch) |

SPEAKERS, DIAL PARTS, CABINETS & MISCELLANEOUS

| Part No. | Description |
|----------|---------------------------------|
| 10-5181 | Chassis Mounting Screw per dos. |
| 28-5188 | Dial drive pulley (rubber) |
| 83-2357 | Orillite cloth (Ivory rayon) |
| 29-13470 | Tuning shaft retaining washer |
| 29-13563 | Dial drive cord (16" long) |
| 34-13360 | Dial drive takeup spring |
| 17-14997 | Needle cup |
| 17-14998 | Needle cup cover |
| 19-15476 | Tuning condenser drive pulley |

