



- MECHANICAL ALIGNMENT:-**
1. Rotate shaft of tuning unit until carriage is against top stop position.
  2. Space oscillator coil slug 1-5/32" out from top of oscillator coil form.
  3. Space R.F. coil slug 1-29/64" out from top end of R.F. coil winding. (Note: The distance 1 and 2 should be measured from mounted end of the slug)
  4. Adjust screw on trimmer of wave trap towards open position so that condenser plates are open at least 1/32".



**Chancellor** Model No. 6W  
 Radionic Equipment Co.