

## PARTS LIST—MODEL 6H2

\* Figures in 2nd last column refer to parts shown in wiring diagram of Model 6H2

Qty.	Part No.	Description	Item	Qty.	Part No.	Description	Item
1	G3-32000	Antenna Coil (Low Freq.)	2	1	B30375A	Cable & Plug	67
1	G1-32002	Antenna Coil (High Freq.)	3	1	W28532	Level Control (Volume) (3 Megohms)	58
1	G2-32001	R. F. Trans. Coil (L. F.)	4	2	G4-27134	Dial Light Brkt Assm.	59-60
1	G1-32001	R. F. Trans. Coil (H. F.)	5	1	W23594B	Tone Control (80000 Ohm) & Line Switch	1
1	G2-32002	Oscillator Coil (L. F.)	6	1	G16-26719	Ant.-Gnd. Terminal	
1	G1-32002	Osc. Coil (H. F.)	7	<b>FILTER &amp; BY-PASS CONDENSERS</b>			
1	G9-32004	1st I. F. Trans. (With Trimmers)	8-19	1	W29097C	8.-8.-8. Mfd. 450 V.-450 V.-250 V.	37-38
1	G10-32004	2nd I. F. Trans. (With Trimmers)	9-20	1	W26194B	12. Mfd. 475 V.	39
6	W25200	Coil Shield Socket	21	1	W30321	1. Mfd. 160 V.	36
3	W30802	Coil Shield		1	W30329	0.02 Mfd. 200 V.	32
2	W25025A	Coil Shield		3	W32370	0.0014 Mfd.	22
1	W25025A	Coil Shield		1	W32304	0.00017-0.006 Mfd. 200 V.-200 V.	25
3	W26891	Insulating Washer L. F. Ant. R. F. and Osc.	2-4-6	1	W30322A	0.001-0.03 Mfd. 400 V.-400 V.	24
2	W21541B	Retaining Ring	2-4-6	1	W25537A	0.01 Mfd. 400 V.	26-27
3	W30026	Retaining Ring	3-5-7	1	W30805	0.01 Mfd. 400 V.	28-29
1	G1-33008	L. F. & H. F. Antenna Trimmer Cond.	11-12	1	W32378	0.01 Mfd. 400 V.	30
1	G1-33008	L. F. & H. F. R. F. Trimmer Cond.	13-14	1	W24784	0.25 Mfd. 200 V.	31
1	G15-33009	L. F. & H. F. Osc. Trimmer Condenser	15-75	1	W25517	0.008-0.05 Mfd. 400 V.-400 V.	33
1	G2-33007	L. F. & H. F. Osc. Serlea Trimmer Cond.	16-17	1	W27540	0.0005 Mfd. 400 V.	34-35
1	G19-33002	Variable Tuning Condenser Gang	10	1	W28589	350 Ohms (Flexible)	41
1	G5-32066	Dial Drive Assm.		1	21433	40000 Ohms	42
1	W32208A	Dial Hand		4	23785	50000 Ohms	43-48
2	W32293	Dial Hand Nut		2	26577	3 Megohms	50-53
1	G75-27456	6D6 Socket	61	1	W27504	100 Ohms (Flexible)	44-46
1	G47-27456	6A7 Socket	62	1	21454	1 Megohm	45
1	G48-27456	6B7 Socket	63	1	23403	150000 Ohms	47
1	G80-27456	76 Socket	64	1	21876	10000 Ohms	49
1	G25-27456	42 Socket	65	1	24814	7000 Ohms	51
1	G6-27456	80 Socket	66	1	33474	120000 Ohms	52
3	W26010	Tube Shield Base		1	W31883	8500-25000 Ohms	54
2	W27328A	Tube Shield (6A7, 6B7)		3	W32352	Knob	56-57
1	B26009C	Tube Shield (6D6)		1	W32353	Knob	
1	G6-30745	Power Transformer 60 cy. 110 V.	71	1	W31007A	Speaker Cord (4 Lead)	
1	G7-30745	Power Transformer 25 cy. 110 V.	72	1	W32219A	Dial Glass	
1	G8-30745	Power Transformer 25 cy. 220 V.	73	1	W32220A	Dial Glass Retainer	
1	B32285	Band Change Switch	74	1	B32190C	Escutcheon	
				1	W33106A	Escutcheon Gasket	
				1	D28	Escutcheon Screws (.10 doz)	

