



WIRING DIAGRAM—MODEL 726

The Crosley Corp.

PARTS LIST—MODEL 726

Figures in first column refer to parts in Diagram

Item No.	Part No.	Description	Item No.	Part No.	Description
1ABC	W-37922	Dial Light	44	-36319	Resistor, 75,000 Ohm 1/2 W.
2	G3-37965	Socket Ass. Dial Light	45A	-36228	Resistor, 60,000 Ohm 1/2 W.
3	G110-32906	Coil Ant. 540-1800 Kc.	45B	-45928	Resistor, 60,000 Ohm 1/2 W.
4	G111-32900	Coil Ant. 1800-6000 Kc.	46	-36321	Resistor, 600,000 Ohm 1/2 W.
5	G112-32900	Coil Ant. 6-18 Mc.	47	-36223	Resistor, 750,000 Ohm 1/2 W.
6	G76-32901	Coil R F 540-1800 Kc.	48	-36322	Resistor, 500,000 Ohm 1/2 W.
7	G86-32901	Coil R F 1800-6000 Kc.	49	-37377	Resistor, 20,000 Ohm 1 W.
8	G90-32901	Coil R F 6-18 Mc.	50	-35929	Resistor, 150,000 Ohm 1/2 W.
9	G115-32902	Coil Osc. 560-1800 Kc.	51A	-35601	Resistor, 300,000 Ohm 1/2 W.
10	G121-32907	Coil Osc. 1800-6000 Kc.	51B	-35601	Resistor, 300,000 Ohm 1/2 W.
11	G122-32902	Coil Osc. 6-18 Mc.	51C	-35601	Resistor, 300,000 Ohm 1/2 W.
12	G120-32904	2nd IF Assy.	52A	-35930	Resistor, 200,000 Ohm 1/2 W.
13	W-36053	Condenser, 355Mf. 400V.	52B	-35930	Resistor, 200,000 Ohm 1/2 W.
14	W-36057	Condenser, 40Mf. 250V.	53	W-30127	Resistor, 40 Ohm 1/2 W. Flex
15	W-41081	Condenser, 16Mf. 250V.	54	W-23012A	Resistor, 40 Ohm 1/2 W. Flex
16A	W-36541	Condenser, 03Mf. 100V.	55	W-6705	Resistor, 3500 Ohm 1 W.
16F	W-30965	Condenser, 01Mf. 400V.	56A	W-28589	Resistor, 350 Ohm 1/2 W. Flex.
18	W-32936	Condenser, 05Mf. 200V.	56B	W-28589	Resistor, 350 Ohm 1/2 W. Flex.
19	W-32908B	Condenser, 03Mf. 400V.	56C	W-28589	Resistor, 350 Ohm 1/2 W. Flex.
20	W-32378	Condenser, 01Mf. 400V.	577	W-37781	Resistor, 16,500 Ohm 1/2 W.
21A	W-35139	Condenser, 004Mf. 400V.	57X	W-37781	Resistor, 16,500 Ohm 1/2 W.
21B	W-35139	Condenser, 004Mf. 400V.	63A	G151-36400	Socket Type 6K7
21C	W-35139	Condenser, 004Mf. 400V.	63B	G151-36400	Socket Type 6A8
22	W-39621	Condenser, 02Mf. 200V.	64	G156-36400	Socket Type 6B6
23	W-32601	Condenser, 02Mf. 100V.	65	G156-36400	Socket Type 6E5
24	W-30323	Condenser, 01Mf. 250V.	67	G155-36400	Socket Type 6N6
25	W-39619	Condenser, 009Mf. 200V.	68	G154-36400	Socket Type 5Z4
26	W-25433	Condenser, 003Mf. 400V.	69	C-4010A	Band Selector Switch
27A	G2-34002	Condenser, 0001Mf. Mica	702		Fidelity Switch
27B	G2-34002	Condenser, 0001Mf. Mica	703	B-42387C	Fidelity Switch
28	G48-34002	Condenser, 0001Mf. Mica	70X	C-42301	Line Switch
29	G3-34002	Condenser, 0005Mf. Mica	71	-615C33	Speaker "M" Spec. 1D640
30	G3-34002	Condenser, 00025Mf. Mica			For Above Speaker
31	G20-34000	Condenser, 4910Mf. Mica			Field Coil
32	G7-34000	Condenser, 140Mf. Mica			Outn. 1 Trans.
33	40768	Condenser, B. C. Osc. Series Trim			Ant. & C. Ind. Terminal Assy.
34	32951	Condenser, 3 Section Trimmer	72	-42260	Power Trans 60 Cv. 110 V.
35	G32-34002	Condenser, 3 Gang Var Tuning	73	42261	Power Trans 25 Cv. 110 V.
	42253	Dial Drive Assy.	74	-42501	Vacuum Control S. Reg.
	42493	Dial Glass (Calibrated)			Misc. Parts
	42500	Drive Unit	C-42045		Escutcheon
	42597	Dial Mark. Cardboard	B-42013		Escutcheon Rubber
	42180	Dial Hand Pointer	D-30		Screws - Escutcheon Mtg.
	41114	Dial Hand, Time Loss	C-42044		Emboss - Escutcheon
	40486	Pointer Mfg. Series	W-40250P		Emboss
36	G1-34002	Condenser, 0025 Mf. Mica	W-3920		Nut - Emboss Mtg.
37	W-40486	Condenser, 001 Mf. 400V.	W-39117		Rubber Mtg. Part
40	W-32982A	Power Cord & Plug	W-37339		Knob 1/2 Res.
41	G3-35996	Cable Speaker	W-40192B		Knob, B. S. Sw. (1 Req.)
42	37245	Resistor, 100,000 Ohm 1/2 W.	W-42490		Knob, S. S. (1 Req.)
43	35600	Resistor, 100,000 Ohm 1/2 W.	W-6NG		Cabinet