

RADIO RECEIVER ALIGNMENT PROCEDURE

PRELIMINARY

- Output Meter Connections.....Plate to Plate of 6K6G's
- Generator Ground Connection.....To chassis or Ground Lead
- Dummy Antenna to be in series with generator output.....See Chart Below
- Position of Volume Control.....Fully On
- Position of Tone Control.....Treble or Speech
- Position of Function Switch.....Radio
- Position of Mike Level Control.....All the Way to Left (Off)

Align-ment Sequence	Dummy Antenna	Frequency Setting	Input Connection to Receiver	Band Switch	Tuning Cond. Setting	Trimmer Adjusted	Remarks
1.	.02 MF.	455 Kc.	Grid of 6A8GT	B. C.	Fully open	2nd I-F (2) 1st I-F (2)	Adjust for Maximum. Adjust for Maximum.
2.	.0002 MF.	1650 Kc.	Ant. Lead (Blue)	B. C.	Fully open	B. C. "OSC" Trimmer	Adjust for peak; gang does not have to tune thru signal.
3.	.0002 MF.	600 Kc.	Ant. Lead (Blue)	B. C.	Approx. 60 on dial	B. C. "OSC" Series Trimmer	Adjust for maximum output while rocking gang thru signal.
4.	Repeat Step No. 2 to check possible shift due to series adjustment						
5.	.0002 MF.	1400 Kc.	Ant. Lead (Blue)	B. C.	Approx. 140 on dial	B. C. "ANT" Trimmer B. C. "PRE" Trimmer	Adjust for maximum output to not touch B. C. Osc. Trimmer. Adjust for maximum output.
6.	400 ohm (carbon)	5.3 Mc.	Ant. Lead (Blue)	Police	Fully open	Pol "OSC"	Adjust for peak gang; does not have to tune thru signal.
7.	400 ohm (carbon)	5.0 Mc.	Ant. Lead (Blue)	Police	Approx. 5.0	Pol "ANT"	Adjust for maximum output while rocking gang thru signal.
8.	400 ohm (carbon)	18.3 Mc.	Ant. Lead (Blue)	S. W.	Fully open	S. W. "OSC"	Adjust for peak. Gang does not have to tune thru signal.
9.	400 ohm (carbon)	18.0 Mc.	Ant. Lead (Blue)	S. W.	Approx. 18	S. W. "ANT"	Adjust for maximum output while rocking gang thru signal.

When aligning the shortwave bands "OSC" trimmers care must be exercised to see that the circuits are aligned on the correct frequency and not on the image which is approximately 910 kilocycles less as indicated on the dial. To check, increase generator output, tune-in the generator frequency and then tune-in the image frequency which should be weaker than the fundamental and come in approximately 910 kilocycles lower on the dial than the fundamental. If image cannot be tuned-in, the "OSC" trimmer is adjusted to the wrong peak. (Correct peak is the second peak on trimmer from the closed position).

Repeat the original alignment procedure for more accurate adjustments. Always keep signal generator output as low as possible to prevent action of the A.V.C. circuit.

**SOCKET VOLTAGES MEASURED @ 117.5 VOLTS LINE (BETWEEN SOCKET PIN AND CHASSIS)
WITH 1000 OHM PER VOLT, 500 VOLT RANGE VOLTMETER (D. C.)
PIN NUMBER**

TUBE FUNCTION	1	2	3	4	5	6	7	8
8SK7—Pre-Amp.	0	0	0	J. B.	*6.3	52
6A8GT—Osc.-Mod.	0	0	198	76.5	0	132	*6.3	1
6SK7—I. F. Amp.	0	0	2.4	0	2.3	76.5	*6.3	226
6SQ7—Det. A. V. C.-A. F.	0	0	0	0	0	98	*6.3	0
6J5GT—Phase Invert.	0	0	118.5	0	0	J. B.	*6.3	6.0
6K6G—Output	0	0	226	236	0	J. B.	*6.3	15.5
6K6G—Output	0	0	226	236	0	J. B.	*6.3	15.5
5Y3G—Rectifier	NC	310	J. B.	*300	J. B.	*300	J. B.	310

*Measure with A. C. Voltmeter.

- MAX. POWER OUTPUT @ 117.5 V. LINE..... 50 Watts
- POWER CONSUMPTION @ 117.5 V. LINE..... 66 Watts (Radio Only)
- TOTAL POWER CONSUMPTION @ 117.5 V. LINE.....110 Watts (Including Phono Motor)
- DROP ACROSS SPEAKER FIELD..... 74 Volts

Voltages may vary 10% of values given.

J. B.—JUNCTION BLOCK

N. C.—NO CONNECTION