



CAPACITY PICK UP WIRE
ANTENNA COUPLER
CATHODE CHOKER
C. BROADCAST ANTENNA
D. SHORT WAVE ANTENNA
E. BROADCAST OSCILLATOR
F. SHORT WAVE OSCILLATOR

BAND SWITCH SHOWN IN 3 W POSITION.
SWITCH IS THREE POSITION FOR 3 W D.C. A PHONO MOTOR SOCKET.

PHONO MOTOR SOCKET

PHONO MOTOR SOCKET