


**GAMME D'ONDA**


OM: 520 — 1605 KHz

OC: 5,9 — 16,5 MHz

FI: 459 KHz



COMMUTAZIONE ELETTRICA CORRISPONDENTE ALLA TASTIERA



L 852 ANT. EST. OM

L 851 ANT. OC

L 853 OSC. OC

L 854 OSC. OM

L 855 I. F. I.

L 856 II. F. I.

L 857 III. F. I.