



IDENTIFICATION NO. 112-407

PARTS LIST

SCHEMATIC SYMBOL	PART NUMBER	DESCRIPTION	SELLING PRICE EACH.	SCHEMATIC SYMBOL	PART NUMBER	DESCRIPTION	SELLING PRICE EACH.
T1	11339A071	Coil-Input I.F.	1.00	C1	Cond. .005 MFD 500V	.15	
T2	11339A072	Coil-Output I.F.	1.00	C5	" .25 " 200V	.20	
L1	11328A073	Coil-Antenna	.75	C6	" .2001 " Mica	.15	
L2	11328A074	Coil-Oscillator	.40	CR C9	Resistor 47K Ohm 1/2W	.15	
R6	11328A075	Control Volume	.65	R1	" 25K " 1/2W	.10	
	11339A072A	500M Ohm with Switch	3.50	R2	" 25K " 1/2W	.10	
	11339A072B	Transformer	1.50	R3	" 2.2M Ohm 1/2W	.10	
	11339A072C	Fixed Coil	4.20	R4	" 150 " 1W	.10	
	11339A072D	Coils & Voice Coil	2.50	R7	Socket-5 Pin	.10	
	11339A072E	Grid-Cap	.25	R8	Push Button Selector	1.85	
C1, C2	11339A072F	Cond. Variable	2.00				
C15	11320A073	Cond. Electrolytic	.60				
C16	11320A074	Cond. Electrolytic	.45				
C4, C7		40 MFD 150 VOLT	.15				
C11		Cond. .05 MFD 200V	.15				
C12		" .05 " 400V	.15				
C10, C11		" .01 " 200V	.15				

