CROSLEY

MODELS 9-102, 9-118W



R. F. AMPLIFIER



I. F. AMPLIFIER



POWER OUTPUT



POWER TRANSFORMER

CONVERTER



DET.-AVC.-1st. A.F.AMPL.



RECTIFIER



NOTES:
1. Bottom View Of Sockets
2. Measure Voltage From Socket Lug To -B(Chassis)
3. Voltages Measured With An Electronic Voltmeter
4. W.J. = Wiring Junction.
5. N.C. = No Connection.
6. * = A.C. Voltage.
7. Voltage Tolerance, 10%
8. Line Voltage 117 V_L 60 ~ A.C.

SOCKET VOLTAGE CHART