

PHILCO RADIO-PHONOGRAPH MODEL 50-1420

PHILCO RADIO-PHONOGRAPH MODELS 50-1421 50-1422 AND 50-1423

These two models are similar to Model 50-1420.

Section 1—Power Supply

For the tests in this section, use a d-c voltmeter. Connect the negative lead to B—, test point B; connect the positive lead to the test points indicated in the chart. The voltage readings given were taken with a 20,000-ohms-per-volt meter at a line voltage of 117 volts, a.c.




Figure 1. Bottom View, Showing Section 1 Test Points

| STEP | TEST POINT | NORMAL INDICATION | ABNORMAL INDICATION | POSSIBLE CAUSE OF ABNORMAL INDICATION |
|------|------------|-------------------|---------------------|--|
| 1 | A | 120 volts | | Trouble in this section. Isolate by the following tests. |
| 2 | C | 212 volts | No voltage | Defective: 50Y7GT, 1100. Shorted: C100, C181, C102A. |
| | | | Low voltage | Leaky: C100, C181, C102A. |
| | | | High voltage | Open: R100. |
| 3 | D | 205 volts | No voltage | Defective: 50Y7GT. Shorted: C102B. Open: R100. |
| | | | Low voltage | Leaky: C102B. |
| | | | High voltage | Open: R101, R182, T200*. |
| 4 | A | 128 volts | No voltage | Shorted: C102C. Open: R101 and R182 (in parallel). |
| | | | Low voltage | Leaky: C102C. |
| | | | High voltage | |

* This part, located in another section, may cause abnormal indication in this section.

Section 2—Audio Circuits

For the tests in this section, use an audio-frequency signal generator. Connect the generator ground lead to B—, test point B; connect the output lead through a .1-mf. condenser to the test points indicated in the chart. Set the radio volume control to maximum, and the radio




Figure 2. Bottom View, Showing Section 2 Test Points

| STEP | TEST POINT | RADIO-PHONO SWITCH | NORMAL INDICATION | POSSIBLE CAUSE OF ABNORMAL INDICATION |
|-------|------------|--------------------|---|---|
| 1 (a) | A | Radio | Loud, clear speaker output with moderate generator input. | Trouble in this section. Isolate by the following tests. |
| 1 (b) | E | Phono | | |
| 2 | C | Radio | Clear output with strong input. | Defective: LS200, 35L6GT. Shorted: T200, C203, C281, C304, C202. Open: T200, R204, R285, R200. Leaky: C283. |
| | | | Loud, clear output with moderate input. | Defective: 6A06. Shorted: C200, C205. Open: C201, R202, R201, R206. Leaky: C201. |
| 3 | D | Radio | Loud, clear output with moderate input. | Open: R200 (rotate), C200, WS. Shorted: WS. |
| 4 | A | Radio | Loud, clear output with moderate input. | |
| 5 | E | Phono | Same as step 4. | Open or shorted: WS. |

Listening Test: Distortion may be caused by leaky C201. Distortion on strong signals may be caused by shorted or leaky C200.

TRUBLE SHOOTING

Turn on the power, and set the volume control to minimum.

If the "NORMAL INDICATION" is obtained in step 1, proceed with the tests for Section 2 (audio circuits); if not, isolate and correct the trouble in this section.

Section 3—I-F, Detector, and A-V-C Circuits

For the tests in this section, use an r-f signal generator, with modulated output, set at 455 kc. Connect the generator ground lead to B—, test point B; connect the output lead through a .1-mf. condenser to the test points indicated in the chart.

Set the radio volume control to maximum, and the radio-phonograph switch to the radio position. Rotate the tuning control until the tuning condenser is fully meshed.

If the "NORMAL INDICATION" is obtained in step 1, proceed with the tests for Section 4 (r-f and converter circuits); if not, isolate and correct the trouble in this section.

To provide a complete i-f amplifier check, test point A for this section is placed at the grid of the mixer in Section 4; therefore, the effectiveness of step 1 as a master check is dependent upon the condition of certain parts in the mixer circuit. These parts are listed below under "POSSIBLE CAUSE OF ABNORMAL INDICATION."

TRUBLE SHOOTING




Figure 3. Bottom View, Showing Section 3 Test Points

| STEP | TEST POINT | NORMAL INDICATION | POSSIBLE CAUSE OF ABNORMAL INDICATION |
|------|------------|---|--|
| 1 | A | Loud, clear speaker output with weak generator input. | Trouble in this section. Isolate by the following tests. |
| 2 | C | Loud, clear output with strong input. | Defective: 12BA6, 6A06. Shorted: C300B, C301A, C301B, C301C, C381D, C303, C304, WS, L300B, L301A, L301B. Open: R302, R303, R304, R305, L300B, L301A, L301B, R301, C301A, C301B. Leaky: C303, C304. Misaligned: Z301. |
| | | | Defective: 12BE6*. Shorted: C400A*, C400B*, C300A, L300A, L300B, C302. Open: L300A, R300, C300A, C300B. Misaligned: Z300. |
| 3 | A | Loud, clear output with weak input. | |

* This part, located in another section, may cause abnormal indication in this section.

Section 4—R-F and Converter Circuits

For the tests in this section, with the exception of the oscillator test, use an r-f signal generator with modulated output. Connect the generator ground lead to B—, test point B; connect the output lead through a .1-mf. condenser to the test points indicated in the chart.

Set the radio volume control to maximum, and the radio-phonograph switch to the radio position. Set the tuning control and signal-generator frequency as indicated in the chart.

If the "NORMAL INDICATION" is obtained in step 1, further tests should be unnecessary; if not, isolate and correct the trouble in this section. If the trouble is not revealed by the tests for this section, check the alignment.

TRUBLE SHOOTING




Figure 4. Bottom View, Showing Section 4 Test Points

| STEP | TEST POINT | SIG. GEN. FREQ. | RADIO TUNING | NORMAL INDICATION | POSSIBLE CAUSE OF ABNORMAL INDICATION |
|------|------------|-----------------------------|-----------------------|---|---|
| 1 | A | 1000 kc. | Tune to signal. | Loud, clear speaker output with weak generator input. | Trouble in this section. Isolate by the following tests. |
| 2 | C—D | Osc. Test (see note below). | Rotate through range. | Negative 1.8 to 3.2 volts. | Defective: 12BE6. Shorted: C400, C400B, C402, C401, L400A, L400B. Open: C402, L400A, L400B, R401, R402. |
| | | | | | Shorted: LA400, C400, C400A. Open: LA400, C404. |
| 3 | A | 1000 kc. | Tune to signal. | Same as step 1. | |

OSCILLATOR TEST: Connect the positive lead of a high-resistance voltmeter to the oscillator cathode (pin 2 of 12BE6), test point D; connect the prod end of the negative lead through a 100,000-ohm isolating resistor to the oscillator grid (pin 1 of 12BE6), test point C. Use a suitable meter range, such as 0–10 volts. Proper operation of the oscillator is indicated by negative voltage within the range given in the chart (measured with a 20,000-ohms-per-volt meter) throughout the tuning range.





Figure 5. Philco Model 50-1420, Sectionalized Schematic Diagram, Showing Test Points

ALL VOLTAGES MEASURED FROM B— WITH A 20,000-OHMS-PER-VOLT VOLT METER AT A LINE VOLTAGE OF 117 VAC

* VOLTAGE MEASURED WITH 100,000 OHM RESISTOR IN SERIES WITH NEG PROD



Philco TROUBLE-SHOOTING Procedure


For rapid trouble shooting, the radio circuit is divided into four sections, as follows:

- Section 1—the power supply
- Section 2—the audio circuits
- Section 3—the i-f, detector, and a-v-c circuits
- Section 4—the r-f and converter circuits

Test points are specified for each section, and are indicated in the sectionalized schematic diagram. The trouble-shooting procedure given for each section includes a simplified test chart and a bottom view of the chassis showing the locations of the test points and the components of that section.

In each chart, the first step is a master check for determining whether trouble exists in that section, without going through the entire chart.

Failure to obtain the "NORMAL INDICATION" in any given step indicates trouble within the circuit under test.



SECTION 1—POWER SUPPLY