



NOTES :

1. SELECTOR SWITCH SW2 IS SHOWN IN EXTREME CLOCKWISE POSITION OR AM BAND. EXTREME COUNTER CLOCKWISE POSITION IS FM BAND.
2. ALL VOLTAGES MEASURED FROM CHASSIS (GROUND) USING A 20,000 OHM/VOLT METER. LINE VOLTAGE SET AT 117V. A.C. VOLTAGES SHOULD BE AS SHOWN \pm 20 PER CENT.

3. TO BE INSTALLED FOR ALIGNMENT ONLY.

4. C38 MAY OR MAY NOT BE PART OF C29.

5. ALL CAPACITANCE VALUES IN MFD AND ALL RESISTANCE VALUES IN OHMS UNLESS OTHERWISE SPECIFIED.

MODELS H-334T7U AND H-335T7U CHASSIS V-2136-5U

There are a number of other Westinghouse receivers designed for AM and FM reception which use the same type of tubes and utilize circuits very similar to V-2136-5U here described. These models are tabulated at right:

Chassis	Models	Type	Changer
V-2136	H-307T7, H-308T7, H-324T7U, H-325T7U	Table Table	
V-2136-1	H-316C7, H-317C7, H-326C7	Comb. Comb.	V-9481 V-9840
V-2136-2	H-324T7, H-325T7	Table	
V-2136-4	H-328C7	Comb.	V-9481

Westinghouse Models H-334T7U and H-335T7U, Chassis V-2136-5U

ALIGNMENT BROADCAST BAND

Connect an output meter across the speaker voice coil.

While making the following adjustments, keep the volume control set for maximum output and the signal generator output attenuated to avoid AVC action.

Check the dial pointer position by meshing the tuning capacitor plates completely and seeing that the dial pointer is set on the end mark of the dial scale.

Step	Connect Signal Generator to —	Signal Generator Frequency	Radio Dial Setting	Adjust
1	Set the band switch to AM			
2	Stator of tuning capacitor (A) through a 0.1 mfd capacitor	455 kc.	minimum capacity	Pri. and sec. of T6 and T5 for max. output in order given
<i>NOTE: If the I-F transformers are badly mis-aligned, it may be impossible to obtain sufficient output using the above system. In this event, it will be necessary to align each transformer separately. Start with the last I-F transformer and work forward, connecting the signal generator to the control grid of the tube preceding the transformer under alignment.</i>				
3	Radiated signal (no actual connection)	1615 kc.	minimum capacity	AM osc. trimmer (D) for max. output
4	Radiated signal (no actual connection)	1400 kc.	tune to signal	AM R-F trimmer (B) for max. output (rock-in adjustment)

FM BAND

Do not align the FM circuits until all AM adjustments have been completed.

Step	Connect Signal Generator to —	Signal Generator Frequency	Radio Dial Setting	Adjust
1	Set the band switch to FM			
2	Connect two 100,000 ohm resistors (the resistances must be equal within 5 per cent) between pin No. 7 of the 12AL5 tube and ground as shown on the schematic diagram.			
3	Connect a V.T.V.M. between points "X" and "Y" (see schematic diagram).			
4	Pin No. 7 of 12AT7 through a .01 mfd mica capacitor	10.7 mc.	minimum capacity	Sec. of T3 for zero (use medium strength signal)
5	Connect the V.T.V.M. between point "Z" and ground.			
6	Same as step 4	10.7 mc.	minimum capacity	Pri. of T3 and pri. and sec. of T1 and T2 for maximum voltage
7	Reconnect the V.T.V.M. between points "X" and "Y" and increase the signal strength 10 times.			
8	Same as step 4	10.7 mc.	minimum capacity	Recheck sec. of T3 for zero voltage
9	Reconnect the V.T.V.M. between point "Z" and ground.			
10	Same as step 4	10.7 mc.	min. cap.	Pri. of T3 for maximum voltage
11	Remove the two 100,000 ohm resistors that were inserted in step 2.			
12	FM ant. terminal through a 300 ohm non-inductive resistor	98 mc.	98 mc.	FM osc. core for maximum voltage
13	Same as step 12	98 mc.	98 mc.	FM R-F trimmer (C32) for maximum voltage
14	Same as step 12	105 mc.	tune to signal	FM R-F core for maximum voltage
15	Same as step 12	90 mc.	tune to signal	FM R-F trimmer (C32) for maximum voltage (rock-in)
16	Recheck steps 14 and 15 for tracking.			

