

SERVICE MANUAL

CS-1820

DUAL TRACE OSCILLOSCOPE



TRIO

FEATURES

- The vertical axis provides high sensitivity (5 mV/div) and wide bandwidth 20 MHz (–3dB). [2 mV, 15 MHz (–3 dB) with 5 ► 2 mV switch]
- The CRT has a rectangular with internal graticule, post deflection accelerator with domed mesh to eliminate parallax errors.
- Delay sweep function that enlarges any given portion of signal for easy observation.
- ALT delay sweep function individually sets for delay and nondelay observations of CH1 and CH2 slopes of internal and external sync signals.
- Distortion-free observation of signals up to 20 MHz.
- Selection of 5 sync signals, ALT, CH1, CH2, LINE and EXT.
- Sync coupling for AC, LFREJ, HFREJ, and DC assures stabilized synchronization of various types of waveforms.
- ALT and CHOP switched are provided for ALT or CHOP observation throughout all ranges.
- Auto free-run system enables the trace to be checked even at no-signal time.
- HOLDOFF function for stabilized synchronization of complex signals such as video signals and logic signals.
- X-Y changeover system allows CH1 amplifier to be used as Y axis amplifier and CH2 amplifier as X axis amplifier.
- The adoption of ICs in the logic changeover circuit provides for improved reliability.

CONTENTS

FEATURES	1
SPECIFICATIONS	2
CIRCUIT DESCRIPTION.....	5
BLOCK DIAGRAM.....	5
VERTICAL PREAMPLIFIERS	6
MODE LOGIC	6
VERTICAL OUTPUT AMPLIFIER	6
TRIGGER CIRCUIT	6
HORIZONTAL SWEEP.....	7
DELAY SWEEP CIRCUIT.....	8
BLANKING AND INTENSITY CONTROL	8
POWER SUPPLIES.....	9
AUTO FOCUS CIRCUIT	9
MAINTENANCE.....	10
ADJUSTMENT	12
TROUBLE SHOOTING	18
PARTS LIST	25
P.C. BOARD	32
DISASSEMBLY.....	37
SCHEMATIC DIAGRAM	39

SPECIFICATIONS

Cathode Ray Tube

Type:

140 CGB 31

Acceleration voltage:

6 kV

Scale:

8 div × 10 div (1 div ≅ 9.5 mm)

Vertical Axis (CH1 and CH2)

Deflection factor:

2 mV/div — 5 V/div ± 3%

Attenuator:

5 mV/div to 5 V/div in 1-2-5 sequence.

Variable between ranges, ± 5% on all ranges.

Input impedance:

1 MΩ ± 2%

Approx. 23 pF

Frequency response:

DC DC — 20 MHz (within — 3 dB) at 5 mV/div — 0.2 V/div

[DC — 15 MHz (within — 3 dB) at PULL 2 mV/div]

AC 5 Hz — 20 MHz (within — 3 dB) at 5 mV/div — 0.2 V/div

[5 Hz — 15 MHz (within — 3 dB) at PULL 2 mV/div]

Risetime:

23.3 nsec (15 MHz) or less, 17.5 nsec (20 MHz) or less.

Overshoot:

3% or less (100 kHz square wave)

Crosstalk:

Better than — 60 dB (alternate), better than — 40 dB (chop).

Operating modes:

CH1 CH1 only

CH2 CH2 only

DUAL Dual trace

ADD Single trace algebraic sum of CH1 and CH2 (single trace algebraic difference of CH1 and CH2 when CH2 signal is inverted.)

Dual-trace Changeover

TRIG SOURCE in ALT position: Alternate trace

TRIG SOURCE in any position other than ALT: Trace chopped at PULL CHOP.

CHOP frequency:

Approx. 200 kHz

CH2 polarity:

Normal or inverted

Maximum input voltage:

600 Vp-p or 300 V (DC + AC peak)

Maximum undistorted amplitude:

More than 8 div (DC — 20 MHz)

Horizontal Axis (Horizontal input thru CH2 input) [X5 MAG not include]

Deflection factor:

Same as vertical (CH2)

Input impedance:

Same as vertical (CH2)

Frequency response:

DC DC — 2 MHz (within — 3 dB)

AC 5 Hz — 2 MHz (within — 3 dB)

X-Y operation:

With SWEEP TIME/DIV switch in X-Y position, the CH1 input becomes the Y-axis input and the CH2 input becomes the X-axis input. The X-Y position control becomes the horizontal position control.

X-Y phase difference:

3° or less at 100 kHz

Sweep Circuit (Common to CH1 and CH2)

Sweep system:

NORM: Triggered sweep.

AUTO: Automatic sweep. Sweep is obtained without input signal.

Sweep time:

0.2 μs/div to 0.5s/div in 20 calibrated ranges, in 1-2-5 sequence. Variable between ranges, Sweep time accuracy; ± 3%.

Sweep magnification:

Obtained by enlarging the above sweep 5 times (± 10%) from center.

Linearity:

± 3% (± 10% for 0.5 μs and 0.2 μs/div ranges with × 5 MAG)

Triggering

Source:

Internal:

ALT Triggered by CH1 or CH2 vertical input signal.

CH1 Triggered by CH1 input signal.

CH2 Triggered by CH2 input signal.

LINE Triggered by power line frequency.

External:

EXT Triggered by an external signal applied to EXT TRIG jack.

Maximum input voltage:

50 V (DC + AC peak)

Coupling:

AC, LF_{REJ}, HF_{REJ}, and DC

Sensitivity (Based on sine wave):

Coupling	Bandwidth (Hz)	Minimum Sync Voltage	
		INT (div)	EXT (Vp-p)
AC	20 ~ 15M	0.5	1
	10 ~ 20M	1	5
DC	DC ~ 15M	0.5	1
	DC ~ 20M	1	5
LF _{REJ} HF _{REJ}	Attenuate below 10 kHz. Attenuate above 100 kHz.		

SPECIFICATIONS

Video Sync:

FRAME — LINE switch permits triggering from horizontal (LINE) or vertical (FRAME) sync pulses of composite video signal.

HOLDOFF:

Continuously variable from zero (NORM) to more than 10 times (MAX).

Delay Sweep

Delay time:

1 μ s to 100 ms in 5 ranges with vernier adjustment.

ALT:

With ALT triggering source, channel 1 or channel 2 sweep can be independently delayed.

Jitter:

5,000: 1

Intensity modulation:

INTEN switch allows portion of sweep after delay to be intensified.

Calibration voltage:

Square wave, positive polarity
0.5 V \pm 1%, reference level 0 V
1 kHz \pm 3%

Intensity Modulation

Input voltage:

More than +2 V (TTL compatible)

Input impedance:

10 k Ω

Bandwidth:

DC — 5 MHz

Maximum input voltage:

50 V (DC + AC peak)

Trace rotation:

Trace angle adjustable on front panel

Power Requirements

Power supply voltage:

AC 100/120/220/240 V \pm 10%, 50/60 Hz

Power consumption:

Approx. 30 W

Dimensions:

Width: 260 mm (277 mm)
Height: 190 mm (204 mm)
Depth: 375 mm (440 mm)
Figures in () show maximum size.

Weight:

Approx. 8.6 kg

Accessories:

Probe (PC — 22)	2 pieces
Attenuation 1/10	
Input impedance 10 M Ω ,	
less than 18 pF	
Replacement fuse	
0.7 A	2
0.3 A	2
Instruction manual	1 copy

SPECIFICATIONS

CRT 140CGB31 SPECIFICATION

Screen and Shape

Dimensions:

Overall length: 310 mm or less

Face plate dimension: Max 143.5 ± 1.5 mm

Screen shape:

Rectangular, flat face, internal graticule

Deflection and focusing system:

Electrostatic deflection

Electrostatic focusing

Post-deflection acceleration

Color:

Green

Persistence:

Medium short

Heating

Heater voltage:

6.3 V

Heater current:

0.24A

Mechanical Data

3rd plate voltage (E_{b3}):

Max 6.3 V

2nd plate voltage (E_{b2}):

Max 1800 V

2nd grid voltage (E_{c2}):

Max 1700 V

1st grid voltage (E_{c1}):

Max 200 V

Cathode to heater voltage (E_{hk}):

Max 125 V

Voltage between 2nd plate and any deflection plate:

Max 500 V

Display area:

95.0×76.0 mm²




Fig. 1 140CGB31 Graticule




Fig. 2 140CGB31 Basing

CIRCUIT DESCRIPTION




Fig. 3 BLOCK DIAGRAM

CIRCUIT DESCRIPTION

The block diagram, Fig. 3, outlines the circuit breakdown of the oscilloscope. Circuit details are obtained by reference to the schematic diagram.

VERTICAL PREAMPLIFIERS

The vertical section includes identical networks for Channel 1 and Channel 2, each containing an input attenuator network and preamplifier. The outputs of the preamplifiers can be gated to the vertical drive amp. by the vertical switching matrix. The vertical switching matrix through the MODE switch and vertical mode logic, gates only the Channel 1 signal in CH1 mode and X-Y operation, only the Channel 2 signal in CH2 mode, alternately gates each in DUAL mode, or simultaneously gates both in ADD mode.

Channel 1 and Channel 2 preamplifiers contain identical circuitry and circuit operation is the same for both. Channel 1 is described below.

The vertical input attenuator, S103, has two sections. The first provides ratios of 1:1, 10:1, 100:1 and 1000:1. The second section provides ratios of 1:1, 2:1, and 5:1. Together, the two sections give an attenuation sequence or 1-2-5, with the appropriate exponent.

After first attenuation section, FET's Q102a and Q102b form a high-impedance input stage of the vertical preamp. This balanced configuration provides compensation for thermal drift and power supply voltage fluctuations. Q101 and D122 are used for negative over-voltage protection. Positive over-voltage is clamped by Q102a.

Op-amp IC101 feeds the second attenuation section. Q103 thru Q106, Q109 and Q110 further amplify the vertical signal before it reaches the vertical drive amp, transistors Q123 to Q126. Trigger amplifier Q107 and Q108 amplify the signal from the emitters of Q105 and Q106 to provide a signal to the sweep trigger circuits.

The only difference between the CH1 and CH2 preamplifiers is that the CH2 polarity switch, S105, reverses the polarity of the CH2 signal when in the INV position. This is accomplished by switching on either transistor pair Q119/Q122, or Q120/Q121.

MODE LOGIC

The mode of operation (CH1, CH2, DUAL, ADD), S106, is controlled by IC103, IC104, and diodes D101-D108. When CH1 is selected, the IC104 Q output is high and the Q low, which reverse biases D101 and D104, allowing the CH1 signal into the vertical drive amp. D107 and D108 are forward-biased, preventing the CH2 signal from reaching the vertical drive amp. For CH2 mode, the reverse is true. For DUAL mode, both channels are displayed as follows: Below a sweep speed of 0.5 ms/div, the IC104 output switches at a 200 kHz rate. This chops the viewable trace into 5-microsecond segments which are alternately switched between Channel 1 and Channel 2 provide dual trace. The chopping signal (clock pulse) that switches IC104 comes from an oscillator formed by gates IC4a and IC4b, and coupled through IC4c. For sweep speeds greater than

or equal to 0.5 ms/div, the IC104 output switches state after every sweep, therefore alternating the A and B vertical signals for display. Thus, Channel 1 is viewed during one sweep, and Channel 2 is viewed during the next. The clock pulse to IC104 comes from IC4c.

When ADD mode is selected, the signals from both channels are added algebraically and then applied to the vertical drive amp. In this mode both the Q and Q outputs of IC104 must be high, which is done by setting both the set and reset lines of IC104 low.

VERTICAL OUTPUT AMPLIFIER

The output of vertical amplifier feeds into the vertical output amplifier. Q401 and Q402 form a differential amplifier which goes to another differential stage Q403 and Q404. These connect to emitter followers Q405 and Q406, which drive cascode amplifiers Q408, Q410, and Q409, Q411. Negative feedback from the cascode amplifiers goes via inverters Q412 and Q413. Q412, Q418, and Q413, Q419 comprise current sources for the cascode amplifiers.

TRIGGER CIRCUIT

The channel 1 signal is amplified by trigger amplifier Q107 and Q108 and is available at Q127 as a trigger source. Similarly, the Channel 2 signal is amplified by trigger amplifier Q117 and Q118 and is also available at Q127 as a trigger source. Mode logic IC103 determines which signal shall be selected as the trigger. In the CH1 mode, diodes D117 and D120 are reverse biased which allows the signal from Channel 1 to reach Q127. Diodes D116 and D121 are forward biased and prevent the Channel 2 signal from reaching Q127. In the CH2 mode, the opposite is true. In the DUAL and ADD modes, an additional input to IC103 from one section of the SOURCE switch selects the Channel 2 signal if the SOURCE switch is set to CH2, but otherwise selects CH1.

The output of Q127 reaches the trigger coupling section via amplifiers Q16 and Q20. The SOURCE switch selects this signal in the CH1 or CH2 positions, an input from the EXT TRIG jack in the EXT position, or a rectified and filtered modulation envelope of the Channel 1 or 2 signal in the DC position. This signal is routed to FET amplifier Q12 through the COUPLING switch. The signal is direct coupled in the DC position, or capacitively coupled in the AC position. The signal is capacitively coupled through a low pass or high pass filter in the HF REJ or LF REJ positions respectively.

The output of Q12 is DC-coupled to emitter follower Q13, which drives one input (pin 2) of op-amp IC5. The triggering LEVEL control sets a DC reference level into the other input of IC5 (pin 1) via Q14a. IC5 acts as a high-gain differential amplifier or Schmitt trigger. When the signal on pin 2 exceeds the DC level on pin 1, the output changes states resulting in a sharp trigger. A trigger of the opposite polarity is developed when the pin 2 level again drops below the pin 1 reference level.

The DC reference from the LEVEL control is disconnected

CIRCUIT DESCRIPTION

and replaced by a DC voltage at the average of the sync trigger input, which is derived by detecting and filtering the signal in the input of Q14. This establishes the threshold reference for IC5 at the center of the waveform being used for triggering.

Both polarities of the IC5 output are applied to the normal sync gates through Q26 and Q27. SLOPE switch S5a enables normal sync gate IC6b in the + position, allowing the Q26 signal to be gated through IC6c, IC9d, and IC9c. In the - position, IC6d is enabled to allow the Q27 signal to be gated through IC6c, IC9d, and IC9c.

When the FRAME-LINE switch is in the FRAME position, IC inhibits the normal sync signals and allows the video sync circuits (Q15, Q28 and Q29) to supply the sweep trigger. The SLOPE switch selects the + or - polarity output of IC5 as the input to Q15, Q28, and Q29. At sweep times of 0.5 s to .1 ms/div, IC7 and IC12 are turned on, which connects capacitor C65 into the coupling circuit between Q28 and Q29. This capacitor shunts the short-duration horizontal sync pulses and allows the longer-duration vertical sync pulses to reach Q29. These slower sweep times are used for viewing vertical frames or fields of video. At sweep times of 50 μ to .2 μ s/div, IC7 and IC12 are turned off and C65 is disconnected. This allows the horizontal sync pulses to reach Q29. These faster sweep times are used for viewing horizontal lines of video.

The trigger pulse output of IC9c is coupled through inverters IC1d and IC1c to the clock input of sweep control multivibrator IC2. This signal synchronizes the sweep to the waveform being used as the trigger source. In the absence of triggering, no sweep is normally developed. However, if PULL AUTO switch S1 is closed, Q6 is enabled and IC2 will free run in the absence of trigger signal. Transistors Q4, Q5, and Q25 when a trigger signal is present.

HORIZONTAL SWEEP

Horizontal deflection is provided by the horizontal preamplifier and horizontal output amplifier. In all except X-Y operation, input to the horizontal preamplifier is furnished by calibrated sweep speed circuits consisting of the sweep control circuit, Miller integrator, and hold-off timer. The sweep can be synchronized to the Channel 1 or 2 input signal or an external trigger. The auto sweep circuit can start the sweep in the absence of a synchronizing trigger. When X-Y operation is selected, the Channel 2 signal is coupled to the horizontal preamplifier for horizontal deflection and the sweep circuits are disabled.

When a trigger pulse is received at the clock input or the reset input of IC2, the Q output (pin 8) goes low. This allows the horizontal ramp integrator to begin the sweep. The integrator consists of Q10, Q11 and the precision sweep timing resistors and capacitors. The sweep speed is determined by the RC time constant of the timing resistors and capacitors set by the SWEEP TIME/DIV control, S2. The output of the integrator, a decreasing linear ramp, is fed through transistors Q8 and Q9, and then to the

horizontal amplifier section, Q17-Q24, and Q31 which drives the horizontal deflection plates. Another output of the sweep integrator, giving an increasing linear ramp, is fed to the threshold input of sweep holdoff timer IC3 (pin 6). When the decreasing ramp voltage has swept the scope trace to the right-hand limit of the sweep cycle on the CRT, the corresponding increasing ramp voltage reaches the threshold setting of IC3. This causes the output of IC3 (pin 3) to go low, which sets the Q output of the sweep control flip-flop, IC2, high. A high at the Q output turns on transistor Q7, which discharges the integrating capacitor and resets the sweep back to the left-hand sweep limit. Simultaneously with the Q output going high, the Q output of IC2 goes low, which sends a high out of the blanking control gate (IC4 pin 11). This turns the trace intensity down, so you cannot see it being reset to the left side of the CRT.

The sweep holdoff time delay capacitor connected to P7 is discharging through VR207, which went low when threshold was reached at IC3 pin 6. When the holdoff time delay cap has discharged to less than 1.6 volts, the timer output, IC3 pin 3, is triggered high. This arms IC2 for the next trigger pulse, coming either from the clock line input (pin 12) or from the reset input when Q25 of the AUTO TRIGGERING circuit is turned on. Along with pin 3, pin 7 of IC3 also goes high and allows the holdoff time delay capacitor to charge up again. The length of the sweep holdoff is determined by the capacitor tied to IC3 pin 2, and the optimum value for each sweep speed is automatically set by the SWEEP TIME/DIV control.

During X-Y operation, set by the SWEEP TIME/DIV switch, the CH2 trigger amplifier output is fed to the horizontal amplifier via Q19 and Q31. In this mode, the CH2 signal controls the horizontal position of the CRT trace.

1. VIDEO Sync

The TV signal (composite video signal) from the vertical amplifier is fed as an internal sync signal to the sync amplifier IC5. The IC5 produces two output signals; one is the same in phase as the input signal and the other is opposite in phase. These signals are positive sync signal (upper side of composite video signal) and negative sync signal (lower side of composite video signal) with respect to the CH1 and CH2 input composite video signals. The output signals are selected by the polarity select switch according to the input signal to obtain a positive sync signal at all times. The signal thus selected is fed to the vertical sync signal detector circuit (Q15, Q28, Q29) where the vertical sync signal is detected by the integration circuit so that the pulses synchronized with the signal is fed to the sweep control gate IC2.

2. DELAY TRIG

When the sweep circuit is in stand-by state, the FF of IC13 is set to ON. With a trigger signal inputted, the FF of IC13 is set to OFF and, at the same time, the trigger signal is fed

CIRCUIT DESCRIPTION

to the delay circuit. The delay signal from the delay circuit passes through the NORM/DELAY selecting gate IC10 and is fed to the sweep control gate IC2 for sweep operation. The IC8 receives the vertical switching signal (IC104). This signal is fed to the IC7 and, at the same time, the NORM/DELAY selecting gate IC10 is controlled by the S204 so that the CH1 and CH2 can be individually delayed.

DELAY SWEEP CIRCUIT

When a trigger signal is received from IC13, signal delayed by the CR time constant is fed back from the IC1a to the sweep circuit. At this time, the FF of the IC13 is set to OFF by the IC1b until the IC1a is reset. The IC2 gives intensity modulation to the starting point of the delay sweep when the INTEND switch S207 is set in the NORM position. In so doing, the sweep is effected in the NORM mode of the delay select switch. The intensity modulation can be adjusted by the VRI for the desired delay sweep. By setting the delay select switch to the DELAY position, the delay trigger pulse is changed to a sweep trigger pulse so that a delay sweep is effected starting with the intensity modulated portion.

BLANKING AND INTENSITY CONTROL

The DC voltage on the intensity grid (pin 4 of the CRT) sets the intensity of the oscilloscope trace. A square wave signal is pulled off the secondary of the high voltage oscillator transformer T301 and amplified by Q302. The peak-to-peak limits of this square wave are determined by D306, D307, D309, and the intensity and blanking control circuitry Q303, Q304, Q305, and Q313. The square wave is ac-coupled into peak detector diodes D304 and D305. The negative peak of the square wave sets the DC voltage on the intensity grid. The more negative this voltage goes, the less the intensity. Intensity Adj., VR302, sets the maximum intensity of the trace. The front panel INTENSITY control VR201 adjusts the trace intensity during normal operation by controlling Q303.

The blanking pulse, which turns the trace intensity down during its return to the left-hand side of the CRT after each sweep, and which keeps the trace off prior to the beginning of a sweep, is generated by sweep control flip-flop IC2 and routed through blanking gates IC4c and IC4d. Blanking pulses during the chopping mode of dual-trace operation also come from blanking gates IC4c and IC4d, which are driven by dual-trace chopping oscillator IC4a and IC4b.

Intensity modulation, or the Z-axis signal, is provided by Q306, which DC-couples the Z-axis input jack to, the intensity control circuit.




Fig. 4 Delay Sweep Block Diagram

CIRCUIT DESCRIPTION

POWER SUPPLIES

The power supply voltages are fully regulated, and a DC-to-DC converter provides a regulated 6 kV accelerating potential to the CRT.

+ 15 Volt Supply

One output of the 14-volt secondary of the power transformer is rectified by diode bridge D319 to become unregulated +15 volts. This is also the source for the +10 volt, +5 volt, and high voltage supplies.

+ 10 Volt Supply

The unregulated +15 volt supply is regulated to +10 volts by Q308, Q315, and Q316.

+ 5 Volt Supply

The regulated +10 volt output is regulated to +5 volts by Q307 and Q314.

– 8 Volt Supply

The other output of the 14-volt secondary of the power transformer is also rectified by diode bridge D319 and regulated to –8 volts by IC301A and Q309.

+ 120 Volt and + 108 Volt Supplies

The 120-volt secondary of the power transformer is rectified by diode bridge D320 and regulated by IC301B and Q310 to +120 volts. Zener diode D318 drops part of the power supply output to a regulated +107 volts.

High Voltage Supply

The +15 volt supply drives a DC-to-DC converter consisting of Q301, Q311, Q312, and T301. Transformer T301 and driver Q301 form an oscillator. Regulation is achieved by feedback transistors Q302, Q311 and Q312. The secondary voltage of T301 is rectified and filtered as +4 kV for the anode of the CRT, –1.3 kV for the cathode, and high voltage for the focus grid. The filaments of the CRT are driven by a secondary of T301, floated at cathode potential.

AUTO FOCUS CIRCUIT

The circuit (Q1, Q2, Q3) is used to invert the intensity modulation signal. The output signal from the circuit varies the amplitude of the oscillator circuit Q4. The voltage set by the FOCUS VR is added to the DC voltage rectified from oscillation waveform and is fed to the FOCUS electrode.

MAINTENANCE

TRACE ROTATION ADJUSTMENT

Strong magnetic fields, present in many locations where an oscilloscope may be used, may cause the trace to be tilted. The degree of tilt may vary as the scope is moved from one location to another. The TRACE ROTATION control provides an electrically adjustable offset to compensate for trace tilt. Perform the adjustment as follows.

1. Set oscilloscope controls to produce a horizontal trace with no input signal (triggering MODE switch in AUTO).
2. Use POSITION controls as required to position the trace along a horizontal line of the graticule scale.
3. Adjust TRACE ROTATION so trace is parallel with the reference line on the graticule scale.

REMOVING THE CASE

Caution:

A high voltage to 6000 VDC is present on the CRT and power supply board when the oscilloscope is operating. Before removing the case be to turn off the power, and do not touch these parts with hand or a screwdriver even after the case has been removed.

The case is removed in two sections, the top section can be lifted off after removing seven Phillipshead screws from the top and sides of the case. The bottom section can be lifted off after removing four Phillipshead screws from the bottom of the case.

AC VOLTAGE CONVERSION

When operating the unit on voltage other than 240 V, set the AC voltage selector switch to 100 V, 120 V or 220 V according to your local AC current. The voltage selector switch is located on the rear panel of the unit as indicated by the arrow mark. When operating on 100 V or 120 V, remove the 0.3A fuse and replace it with one rated at 0.7A.

PROBE COMPENSATION

Probe compensation adjustment matches the probe to the input of the scope. For best results, compensation of both probes should be adjusted initially, then the same probe always used with Channel 1 and Channel 2 respectively. Probe compensation should be readjusted whenever a probe from a different oscilloscope is used, or the Channel 1 and 2 probes are interchanged.

1. Connect probes to both INPUT jacks. Connect ground clip of probes to oscilloscope ground terminal and touch tips of both probes to CAL 1 kHz 0.5 V p-p terminal.
2. Select single trace operation of Channel 1, then Channel 2, for steps 3 and 4.
3. Set oscilloscope controls to display 3 or 4 cycles of CAL square wave at 5 or 6 div amplitude.
4. Adjust compensation trimmer on probe for optimum square wave waveshape (minimum overshoot, rounding off, and tilt).

REMOVING THE CATHODE RAY TUBE (CRT) AND P.C. BOARD

Caution:

This circuit around CRT produce a voltage as high as 6000 VDC. To prevent electric shock, be sure to disconnect the power cord before replacing the CRT. Make certain that the circuits are fully discharged.

REMOVING THE C.R.T.

1. Remove the case (1) and case (2)
2. Remove the CRT bezel.
3. Remove the 2 screws from the CRT band holding the neck of the CRT shield.
4. Remove the 4 screws holding the front panel to the CRT bracket. Then, remove a screw holding a black lead to the leg of the CRT band.
5. Loosen the screw holding the CRT band to the rear panel.
6. Remove the CRT from the CRT socket.
7. Remove the anode cap from the CRT.
8. Lift the CRT shield and slide the CRT forward to remove from the CRT shield and slide the CRT backward to remove from CRT bracket. Remove the tape holding the rotator coil. Slide the rotator coil backward and remove.
9. Remove cable bands using a nipper.
10. The CRT is ready for removal. Replace it with a new one by following the above procedure in reverse order.
11. After replacing, make adjustment of TRACE ROTATION, ASTIG and others referring to the adjustment.

REMOVING THE P.C. BOARD

Removing vertical amplifier board

1. Remove the cases.
2. Remove the decorative panel as follow.
 - 1) Remove the VOLTS/DIV and VARIABLE knobs (both CH1 and CH2)
 - 2) Remove the SWEEP TIME/DIV, DELAY TIME knobs and each VARIABLE knobs.
 - 3) Remove the \blacktriangle POSITION knobs (both CH1 and CH2)
 - 4) Remove the SLOPE, COUPLING and SOURCE lever knobs.
 - 5) Remove the TRIG. LEVEL knob.
 - 6) Remove the $\blacktriangleleft\blacktriangleright$ H.POSITION and HOLDOFF knobs.
 - 7) Remove the MODE and AC-GND-DC (both CH1 and CH2) lever knobs.
 - 8) Remove slotted hex. lock nuts from shaft of VOLTS/DIV (CH1 only), \blacktriangle POSITION (both CH1 and CH2), TRIG. LEVEL, DELAY TIME and $\blacktriangleleft\blacktriangleright$ H. POSITION controls.
3. Remove 2 screws securing the each lever switch from diecasting panel.
4. Unsolder 2 resistors (R203, R204) from BNC receptacle.

MAINTENANCE

5. Remove 2 screws, holding the vertical amplifier board, from P.C. board mounting hardware.
6. Carefully disconnect and remove the connector rearward connecting vertical output amplifier board.
7. Carefully disconnect and remove the connector sideward connecting horizontal sweep board.

Caution:

When disconnecting the connector, carefully disconnect and remove P.C. board to avoid damage of the P.C. board.

Removing horizontal sweep board

1. Remove the case and decorative panel (this is the same procedure that was removed in step 1 and 2 of "Removing vertical amplifier board").
2. Remove each 2 screws securing SLOPE, COUPLING and SOURCE lever switches from die-casting panel.
3. Remove slotted hex. lock nuts from shaft of SWEEP TIME/DIV and HOLDOFF controls.

4. Disconnect the connectors from the terminals. (1–8, 10–12, and 16)
5. Unsolder resistor (R47) from BNC (EXT. TRIG) receptacle.
6. Removing 2 screws, holding the horizontal sweep board from P.C. board mounting hardware.
7. Carefully disconnect and remove J1 and J2 connectors connecting the vertical amplifier board and power supply board.
8. Unplug P1 thru P8 from horizontal sweep board.

Removing vertical output amplifier board

1. Remove the cases.
2. Unsolder 2 yellow leads from CRT socket.
3. Remove 2 screws, securing CRT band from rear panel.
4. Remove 2 CRT bracket.
5. Carefully disconnect and remove J401 and J402 connectors connecting the vertical amplifier board and power supply board.

ADJUSTMENT

To obtain the best performance, periodically calibrate the unit. Sometimes, only one mode need be calibrated, while at other times, all modes should be calibrated. When one mode is calibrated, it must be noted that the other modes may be affected. When calibrating all modes, perform the calibration in the specified sequence.

The following calibration required an accurate measuring instrument and an insulated adjusting flat blade screwdriver. If they are not available, contact your dealer. For optimum adjustment, turn the power on and warm up the CS-1820 sufficiently (more than 30 minutes) before starting.

Before calibrating the unit, check the power supply voltage.

TEST EQUIPMENT REQUIRED

The following instrument or their equivalent should be used for making adjustment.

Test Equipment	Model	Minimum Specification
Digital Multi-Meter	DL-706 (TRIO)	Impedance: More than 10 M Ω , Measuring range: 0.01 V to 199 V
Sine-Wave Generator	651 B (YHP)	Frequency: 10 Hz to 10 MHz, constant voltage over tuning range
Sine-Wave Generator	SG-503 (Tektronix)	Frequency: 50 kHz to 100 MHz, Output impedance: 50 Ω , constant voltage over tuning range.
Square-Wave Generator	PG-506 (Tektronix)	Output signal: 1 kHz, Amplitude: 10 mVp-p to 10 Vp-p, Accuracy: within $\pm 1\%$, Rise time: 35ns or less
Q Meter	4343B (YHP)	—
Color Pattern Generator	CG-911 (TRIO)	—
Oscilloscope	465 (Tektronix)	Sensitivity: more than 5 mV Frequency response: More than 100 MHz
Time-Marker Generator	TG-501 (Tektronix)	Time mark: 0.5 s to 0.1 μ s repetitive waveform
High-Voltage Probe	—	Input Impedance: 1000 M Ω
Termination	—	Impedance: 50 Ω Accuracy: within 3%
Termination	—	3 watts type impedance: 50 Ω
Attenuator	—	- 20 dB attenuation (50 Ω)

PREPARATION FOR ADJUSTMENT

Control Setting

The control setting listed below must be used for each adjustment procedure.

Exceptions to these settings will be noted as they occur.

After completing a adjustment, return the controls to the following settings.

NAME OF KNOBS	POSITION
INTENSITY	3 o'clock
FOCUS	Optimum position
CH1, CH2 POSITION/ PULL 5 \triangleright 2mV	Mechanical position and push
\blacktriangleleft H. POSITION/PULL \times 5MAG	Mechanical position and push
VARIABLE (H, V)	CAL
AC-GND-DC (CH1 and CH2)	DC (GND at no signal)
MODE	CH1
CH2 POLARITY	NORM
SLOPE	+
COUPLING	AC
SOURCE	ALT
TRIG. LEVEL/PULL AUTO	Mechanical center and pull
HOLD OFF/PULL CHOP	NORM and push
FRAME-LINE	LINE
INTEN'D	NORM
CH1 (CHOP)	NORM
CH2	NORM
VOLTS/DIV	5 mV/DIV
SWEEP TIME/DIV	1 ms/DIV

ADJUSTMENT

Item	Adjustment control	Adjustment and check	Remark
POWER AND CRT CIRCUIT ADJUSTMENTS (X68-1270-02)			
+ 108.5 V, + 10 V, + 15 V, + 5 V, - 8 V and + 124 V adjustments and check.	VR304	<ol style="list-style-type: none"> 1. Connect a DC voltmeter to measure the voltage at the pin 8 of P308 with respect to the chassis. 2. Adjust VR304 to obtain + 108.5 V \pm 1% 3. Next, measure the voltages at the pin 4, 7 and 8 of P306. The voltage should be + 10 V, + 15 V, + 5 V, - 8 V and + 124 V respectively. 	
- 1.5 kV adjustment	VR303	<ol style="list-style-type: none"> 1. Connect a DC voltmeter to measure the voltage at the pin 9 of P301 on the high voltage power supply unit with respect to the chassis. 2. Adjust VR303 to obtain - 1.5 kV. 	Caution: Be sure to use the high-voltage prove.
FOCUS and ASTIG adjustments	FOCUS ASTIG	<ol style="list-style-type: none"> 1. Set the SWEEP TIME/DIV control to the X-Y position and CH1 and CH2 AC-GND-DC switches to the GND position. This will produce a spot on the screen. 2. Adjust the FOCUS and ASTIG on the front panel for the sharpest, roundest spot. 	Do not readjust the ASTIG control after this step.
INTENSITY adjustment	VR302	<ol style="list-style-type: none"> 1. Set the TRIG. MODE switch to the AUTO position to display a trace. 2. Adjust VR302 so that the trace disappears when the INTENSITY control setting is reduced to the 10:30 o'clock position. 	
Blanking adjustment	TC301	<ol style="list-style-type: none"> 1. Set the SWEEP TIME/DIV control to 0.2 μs and the TRIG. MODE switch to the AUTO to display a trace. 2. Adjust TC301 until the start point of the trace is the same in thickness as the other. 	
Check of CRT centering		<ol style="list-style-type: none"> 1. Short test terminal P401 to P402 (vertical output amplifier board). 2. Pull the PULL AUTO knob to display a trace. 3. Check the trace to center the trace vertically. 	
VERTICAL AXIS CIRCUIT ADJUSTMENT (X73-1210-02)			
VARI. ATT. BAL. and STEP ATT. BAL. adjustments	VR101 VR103 VR108 VR110	<ol style="list-style-type: none"> 1. Set scope control for a single horizontal trace on CH1 with the CH1 AC-GND-DC switch set to the GND position and set the SWEEP TIME/DIV control to 1 ms. 2. Rotate the CH1 variable control from maximum clockwise to maximum counterclockwise, while observing the trace. 3. If the trace moves vertically, adjust VR101 (VARI. ATT. BAL.) for minimum or zero movement when performing step 2. 4. Rotate the CH1 VOLTS/DIV switch through the 5 mV, 10 mV and 20 mV position while observing the trace. 5. If the trace moves vertically, adjust VR103 (STEP ATT. BAL.) for minimum of zero vertical movement when performing step 4. 6. Repeat the entire procedure for CH2, adjusting VR108 for VARIABLE balance and VR110 (VOLTS/DIV) step balance. 	After adjusting VARI., be sure adjust STEP.


ADJUSTMENT

Item	Adjustment control	Adjustment and check	Remark
2 mV Center adjustment	VR115	<ol style="list-style-type: none"> 1. Set the CH1 AC-GND-DC switch to the GND position and the SWEEP TIME/DIV control to the 1 ms position. 2. Adjust the VR114 so that the trace is stationary when the CH1 VOLTS/DIV control is set to the 2 mV or 5 mV position. 3. Repeat the entire procedure for the CH2, adjusting VR115. 	
CH2 INVERT POLARITY and \blacktriangledown POSITION adjustments	VR112 VR105 VR402	<ol style="list-style-type: none"> 1. Set the CH1 AC-GND-DC switch to the GND, the MODE switch to the DUAL position, and the SWEEP TIME/DIV control to 1 ms. Also, set the TRIG. AUTO switch to the AUTO position. 2. Next, adjust VR112 to make sure that the trace does not sift when the CH2 POLARITY push button switch is set in the PUSH position (INV) (■). 3. Set the CH2 and CH1 \blacktriangledown POSITION controls to these mechanical center. 4. Adjust VR105 and VR402 so that traces are overlapped in the center of the scale. 	
Vertical gain adjustment	VR401 VR110	<ol style="list-style-type: none"> 1. Set the MODE switch to the CH2 position. 2. Apply the CH2 input terminal to 1 kHz square wave signal. 3. Set the CH1 VARIABLE control to the CAL position and the VOLTS/DIV control to 5 mV. 4. Adjust VR401 for exactly 4 divisions vertical amplitude of 1 kHz square wave signal display . 5. Repeat the entire procedure for CH1, adjusting VR110 for vertical gain adjustment. 	
100 kHz square wave compensation	TC401 TC402 TC403 TC405 VR403 VR404 VR405	<ol style="list-style-type: none"> 1. Set the VOLTS/DIV control to 5 mV, the MODE switch to CH2 position and the SOURCE switch to CH2 position. 2. Apply a 100 kHz square wave signal through a 50 Ω terminator to the CH2 input terminal and adjust the vertical amplitude to 6 divisions on the CRT screen. 3. Rotate the SWEEP TIME/DIV control from 2 μs to 0.2 μs. Adjust TC401 thru TC405 and VR403 thru VR405 in the order (a to d), to obtain the optimum waveform at the rising portion of the square wave. <ol style="list-style-type: none"> a. Adjust VR404 to obtain flat mid range. b. Adjust TC403 to obtain flat mid and high ranges. c. Adjust TC402 to obtain maximum overshoot. d. Adjust VR405 and VR403 to obtain minimum overshoot. 	
1 kHz square wave compensation	TC101 TC103 TC105 TC106 TC108 TC110	<ol style="list-style-type: none"> 1. Set the VOLTS/DIV control to 5 mV and apply a 1 kHz square wave signal. 2. Rotate the VOLTS/DIV control to 50 mV (10:1), 0.5 V (100:1) and 5 V (1000:1) positions. 3. Adjust TC101 (10:1), TC103 (100:1) and TC105 (1000:1) to make sure that the vertical amplitude is set to 6 divisions on the CRT screen. 	


ADJUSTMENT




Item	Adjustment control	Adjustment and check	Remark
		4. Repeat the entire procedure for CH2, adjusting TC106 (10:1), TC108 (100:1) and TC110 (1000:1)	
Input capacity adjustment	TC102 TC104 TC111	1. Connect a "Q" meter to measure the input capacity at the CH1 input terminal and make sure that the input capacity is approx. 23 pF. 2. Rotate the VOLTS/DIV control to 50 mV (10:1), 0.5 V (100:1) and 5 V (1000:1), adjusting TC102 , TC104 and TC111 to make sure that the input capacity at each position is the same as that at the 5 mV (1/1) position.	
HORIZONTAL AXIS CIRCUIT ADJUSTMENT (X74-1190-01)			
Waveform spacing adjustment	TC4	1. Set the SWEEP TIME/DIV control to the 0.2 μ s position and the PULL \times 5 MAG knob to the PULL position. 2. Apply a 20 MHz sine wave signal to the V. INPUT to display 2 div vertical amplitude waveform on the screen. 3. Adjust the TC4 to set the starting point and spacing of waveforms.	
Sweep time and sweep length adjustments	VR15 VR6	1. Set the SWEEP TIME/DIV control to 1 ms and apply a 1 ms marker signal to the CH1 input terminal. 2. Adjust VR15 so that a pulse appears on each division on the graticule scale of the CRT screen. 3. Next, adjust VR6 so that the sweep length slightly exceeds 9 divisions (approx. 9.5 divisions, SWEEP TIME/DIV:0.5 μ s – 0.1 μ s not included)	
MAG centering and MAG GAIN adjustments	VR13 VR14	1. With the SWEEP TIME/DIV control to 1 ms, apply a 5 ms marker signal to the CH1 input terminal to display 5 pulses on the CRT screen. 2. Pull the X5 MAG knob to magnify a trace and adjust so that the center of the wave corresponds to the Y-axis on the graticule scale. 3. Push the X5 MAG knob and adjust VR13 so that the center of the trace corresponds to Y-axis on the graticule scale. 4. Next, set the SWEEP TIME/DIV control to 1 ms. 5. With a 1 ms marker signal applied to the CH1 input terminal, adjust VR14 until the center of the 3 pulses corresponds to the Y-axis on the graticule scale.	
◀▶ H. POSITION adjustments	VR10	1. With the SWEEP TIME/DIV control set to 1 ms, apply 5 ms marker signal to the CH1 to display 3 pulses on the CRT screen. 2. Next, set the ◀▶ H. POSITION control to its mechanical center, and adjust VR10 until the center of the 3 pulses corresponds to the Y-axis on the graticule scale.	
1 μ s, 0.5 μ s and 0.2 μ s range adjustments	TC1 TC2 VR5	1. Set the SWEEP TIME/DIV control to 1 μ s, 0.5 μ s and 0.2 μ s while applying the corresponding marker signal (1 μ s, 0.5 μ s and 0.2 μ s) to display 10 waves on the CRT screen. 2. Adjust TC1 , TC2 and VR5 so that each wave is 9 divisions on the graticule scale respectively.	

ADJUSTMENT

Item	Adjustment control	Adjustment and check	Remark
Starting Point adjustment	TC3 TC4	<ol style="list-style-type: none"> 1. Set the SWEEP TIME/DIV control to the 20μs position and the $\triangleleft \triangleright$ H. POSITION/PULL \times 5 MAG knob to the PULL position. 2. Apply to 250 kHz sine wave signal to the V. INPUT to display a 6 div vertical amplitude waveform on the screen. 3. Adjust the TC3 to obtain the waveform starting point as illustrated right. 4. Next, set the SWEEP TIME/DIV control to the 0.2μs position. 5. Apply a 20 MHz sine wave signal to the V. INPUT to display a 2 div vertical waveform. Make even the spacing in the vicinity of the starting point. 6. Adjust the TC4 so that the optimum starting point is obtained when the $\triangleleft \triangleright$ H. POSITION/PULL \times 5MAG knob is set to PULL and PUSH positions. 	
X POSITION adjustment	VR12	<ol style="list-style-type: none"> 1. With the MODE switch set to the DUAL position, overlap the traces of both channels using the CH1 and CH2 \blacktriangleup POSITION controls. 2. The traces should coincide with the X-axis on the graticule scale. 3. Set the SWEEP TIME/DIV control to the X-Y operation and adjust VR12 to bring the spot in the center of the graticule scale. 	
X GAIN adjustment	VR111	<ol style="list-style-type: none"> 1. Set the SWEEP TIME/DIV control to the X-Y operation and the CH2 VOLTS/DIV control to 5 mV. 2. Apply a 1 kHz, 20 mV square wave to the CH2 input terminal and adjust VR111 for exactly 4 divisions horizontal deflection. 	
SYNC ADJUSTMENT			
OFF-SET adjustment	VR7	<ol style="list-style-type: none"> 1. Set the TRIG LEVEL knob to its mechanical center position and short the shorting terminals P14 and P15. Then, connect a calibrated oscilloscope (sensitivity: 0.2V/div, AC-GND-DC). 2. Adjust the VR7 so that the voltage on the P13 is not varied when the SLOPE knob is set to "+" and "-" positions. 	
TRIG LEVEL Center adjustment	VR19	<ol style="list-style-type: none"> 1. Set the TRIG LEVEL control to its mechanical center position. Adjust the VR19 so that the voltage on the P13 remains unchanged when the shorting pins P14 and P15 are removed. 	
"+" and "-" TRIG adjustment	VR17 VR18	<ol style="list-style-type: none"> 1. Set the TRIG LEVEL control to its mechanical center position. Apply a 1 kHz sine wave signal to the CH2 INPUT to display a 6 div vertical amplitude waveform. 2. Reduce the amplitude gradually and adjust the VR18 so that the signal is triggered below 0.5 div. 3. Repeat the entire procedure for the "-" TRIG., adjusting VR17. 	<p>Check that the starting point remains the same when the SLOPE switch is set to the "+" and "-" positions.</p>


ADJUSTMENT

Item	Adjustment control	Adjustment and check	Remark
CH2 DC COUPLING adjustment	VR11 VR20	<ol style="list-style-type: none"> Set the MODE switch to the CH2 position. Apply a 1 kHz sine wave signal to the CH2 to display a 6 div vertical amplitude waveform on the scope. Set the VR20 to its mechanical center position and adjust the VR11 so that the waveform starting point is not changed. 	If this adjustment is not possible with the VR11 , use the VR11 and VR20 alternately.
CH1 DC COUPLING adjustment	VR113	<ol style="list-style-type: none"> Set the MODE switch to the DUAL position and the COUPLING switch to the DC position. Apply a 1 kHz sine wave signal to the CH1 and CH2 to display a 6 div vertical amplitude waveform on the scope. Adjust the VR113 so that the waveform starting points of CH1 and CH2 are the same. 	
CALIBRATING VOLTAGE ADJUSTMENTS (X74-1190-00)			
	VR1 VR2 VR3	<ol style="list-style-type: none"> With a 1 kHz, 0.1 V square signal applied to well calibrated oscilloscope, set the VOLTS/DIV control to 20 mV to display a waveform on the CRT screen as illustrated below. Next, apply a calibrating voltage (\square CAL output) of the unit to the oscilloscope and adjust VR1, VR2 and VR3 until the displayed. 	




TROUBLESHOOTING

TROUBLESHOOTING




TROUBLESHOOTING

1.




- (Note)
1. Parts without particular notes belong to the main body.
 2. X68 - X68-1270-02
 3. X73-1210 - X73-1210-02
 4. X73-1220 - X73-1220-05
 5. X74 - X74-1190-01

2.



TROUBLESHOOTING

3.



4.






Fig. 20 Wave Form in SWEEP Circuit (X74-1190-01)
(Input Signal 2 kHz Sine Wave, SWEEP TIME
0.1 mS/div)



TROUBLESHOOTING

5.



6.







Fig. 21 J1 Clock Pulse Wave Forms at Terminal 5

TROUBLESHOOTING

7.







8.




TROUBLESHOOTING

9.



TROUBLESHOOTING

10.



PARTS LIST

MAIN CHASSIS

Fig. & index	Parts No.	Description
1	A01-0829-03	Case (Top)
2	A01-0835-13	Case (Bottom)
3	A13-0724-23	Frame
4	A20-2749-32	Die casting panel
5	A21-1001-02	Decorative panel
6	A23-1621-22	Rear panel
7	B07-0703-04	Push escutcheon (round, grey) x 2
8	B07-0708-04	Push escutcheon (rectangular, grey)
9	B07-0706-04	Push escutcheon (rectangular, light grey)
10	B07-0752-12	Rear escutcheon
11	B19-0708-04	Filter
12	B30-0919-15	Lamp ass'y
13	B30-0902-05	LED
14	E01-1403-05	CRT socket
15	E03-0201-05	Power connector
16	E04-0251-05	BNC receptacle
17	E21-0654-04	CAL terminal
18	E21-0657-04	Metal terminal
19	F07-0908-14	Grip cover
20	F10-1545-13	Shield plate
21	F10-1540-04	Shield plate
22	F10-1543-04	Shield plate
23	F11-0942-03	CRT shield
24	F15-0713-14	Felt
25	G02-0603-14	Spring
26	G13-0705-04	CRT mounting rubber
27	J10-0094-03	Bezel ass'y
28	J10-0072-02	Bezel
29	B07-0707-03	Bezel frame
30	J13-0033-15	Fuse holder
31	J19-1618-04	CRT band
32	J19-1619-04	CRT band
33	J21-2812-34	P.C.B. bracket
34	J21-2813-34	P.C.B. bracket
35	J21-2814-53	P.C.B. bracket
36	J21-2815-34	P.C.B. bracket
37	J21-2818-54	P.C.B. bracket
38	J21-2891-14	VR bracket
39	J21-2875-15	Gear
40	J21-2876-05	Ring
41	J21-2899-13	CRT Bracket
42	J32-0822-04	Hex. post
43	K01-0507-05	Handle
44	K21-0819-03	Knob
45	K21-0820-04	Knob
46	K21-0822-14	Knob
47	K27-0525-04	Lever knob (black)
48	K27-0526-04	Lever knob (dark grey)
49	K27-0507-04	Push knob (rectangular, grey)
50	K27-0504-04	Push knob (rectangular, light grey)
51	K27-0505-04	Push knob (rectangular, blue)
52		CRT 140CGB31
53	L01-9186-05	Power transformer
54	L39-0509-05	Rotator coil
55	R01-2012-05	Variable res. 5kΩB
56	R01-3027-05	Variable res. 10kΩB
57	R01-8502-05	Variable res. 1MΩB
58	R01-6003-05	Variable res. 250kΩB
59	R03-0503-05	Variable res. 500ΩB
60	R05-8502-05	Variable res. 2MΩB
61	S42-4507-05	Push switch
62	N08-0606-05	Hex. socket head screw
63	W01-0503-04	Cord wrap
64	X73-1210-02	Vertical amplifier unit
65	X73-1220-05	Vertical output unit
66	X74-1190-01	Horizontal sweep unit
67	X74-1200-00	Delay sweep unit
68	X68-1270-02	Power supply unit
69	X77-1020-00	Voltage selector unit
70	S37-2005-05	Lever switch
71	F11-0910-13	Shield case
72	S32-4007-05	Lever switch

Fig. & index	Parts No.	Description
73	R01-0501-05	Variable res. 300ΩB
74	F11-0147-24	Shield case
75	S03-3501-05	Rotary switch
76	R01-1505-05	Variable res. 1kΩB
77	S40-2502-05	Push switch
78	R01-4024-05	Variable res. 50kΩB
79	S29-2504-05	Rotary switch
80	R01-4024-05	Variable res. 50kΩB
81	S33-2501-05	Lever switch
82	S37-2005-05	Lever switch
83	S32-2013-05	Lever switch
84	F10-1510-04	Shield plate
85	F11-0911-33	Shield case
86	J21-2892-04	P.C.B. bracket
	B40-0765-14	Name plate (serial No.)
	B41-0701-14	Voltage indication sheet
	B50-2954-00	Instruction manual
	B40-2799-03	Name plate (CS-1820)
	E23-0505-04	Earth plate
	E23-0520-05	Earth lug
	E23-0513-05	Solder lug
	E31-0713-05	Lead wire/connector 2P
	E30-1818-05	JIS cord
(J-2)	E31-2226-05	Lead wire/connector 4P
(J-1)	E31-0723-05	Lead wire/connector 1P
(J-4)	E31-0689-05	Lead wire/connector 2P
(J-7)	E31-0687-05	Lead wire/connector 4P
(J-8)	E31-0686-05	Lead wire/connector 7P
(J-10)	E31-0660-05	Lead wire/connector 1P
(J-11)	E31-0659-05	Lead wire/connector 3P
(J-13)	E31-0690-05	Lead wire/connector
(J-14)	E31-0533-05	Lead wire/connector 1P
(J-15)	E31-0511-05	Lead wire/connector 4P
(J-16)	E31-0664-05	Lead wire/connector 3P
(J-18)	E31-0554-25	Lead wire/connector 3P
	E31-0680-15	Lead wire/connector
(J-20)	E31-0532-05	Lead wire/connector 1P
(J-21)	E31-0691-05	Lead wire/connector 1P
(J-22)	E31-0693-05	Lead wire/connector 2P
(J-19)	E31-0784-05	Lead wire/connector 4P
	E31-0717-05	Lead wire/connector
	F05-7011-05	Fuse 0.7A
	F05-3011-05	Fuse 0.3A
	F20-0618-04	Insulation sheet
	J02-0089-05	Rubber leg
(L201, 202)	L40-1091-41	Ferri inductor
(R206, 207)	RD14BB2E151J	Carbon res. 150Ω ± 5% 1/4W
(R203, 204)	RD14BB2E220J	Carbon res. 22Ω ± 5% 1/4W
(R205)	RD14BB2E154J	Carbon res. 150kΩ ± 5% 1/4W
	H01-2948-04	Carton box
	H10-2807-02	Pad (foamed styrene)
	H12-0522-04	Pad (carton)
	H20-1701-24	Protection cover
	H25-0029-04	Polyethylene bag

VERTICAL AMPLIFIER (X73-1210-02)

Ref. No.	Parts No.	Description
RESISTOR		
R101	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W
R102	RN14BK2H9003F	Metal film 900kΩ ± 1% 1/2W
R103	RN14BK2E1113F	Metal film 111kΩ ± 1% 1/4W
R104	RN14BK2H9903F	Metal film 990kΩ ± 1% 1/2W
R105	RN14BK2E1012F	Metal film 10.1kΩ ± 1% 1/4W
R106	RN14BK2E4021F	Metal film 4.02kΩ ± 1% 1/4W

PARTS LIST

Ref. No.	Parts No.	Description	Ref. No.	Parts No.	Description
R107	RN14BK2H1004F	Metal film 1MΩ ± 1% 1/2W	R226,227	RN14BK2E91ROF	Metal film 91Ω ± 1% 1/4W
R108	RD14BB2E104J	Carbon 100kΩ ± 5% 1/4W	R228	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W
R109 ~ 111	RD14CB2E220J	Carbon 22Ω ± 5% 1/4W	R229,230	RN14BK2E2201F	Metal film 2.2kΩ ± 1% 1/4W
R112	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	R232	RD14BB2E680J	Carbon 68Ω ± 5% 1/4W
R113 ~ 116	RD14CB2E220J	Carbon 22Ω ± 5% 1/4W	R233,234	RN14BK2E2001F	Metal film 2kΩ ± 1% 1/4W
R117,118	RN14BK2E3901F	Metal film 3.9kΩ ± 1% 1/4W	R235	RD14BB2E680J	Carbon 68Ω ± 5% 1/4W
R119	RD14CB2E681J	Carbon 680Ω ± 5% 1/4W	R239,240	RN14BK2H9963F	Metal film 996kΩ ± 1% 1/2W
R120	RN14BK2E2701F	Metal film 2.7kΩ ± 1% 1/4W	R241,242	RN14BK2E53R6F	Metal film 53.6Ω ± 1% 1/4W
R121	RN14BK2E3301F	Metal film 3.3kΩ ± 1% 1/4W	R243	RD14BB2E471J	Carbon 470Ω ± 5% 1/4W
R122	RN14BK2E2201F	Metal film 2.2kΩ ± 1% 1/4W	R244	RD14BB2E223J	Carbon 22kΩ ± 5% 1/4W
R123	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	R245 ~ 248	RN14BK2E10ROF	Metal film 10Ω ± 1% 1/4W
R124	RN14BK2E1300F	Metal film 130Ω ± 1% 1/4W	R249,250	RD14BB2E5R6J	Carbon 5.6Ω ± 5% 1/4W
R126	RN14BK2E69R8F	Metal film 69.8Ω ± 1% 1/4W	VR101	R12-0527-05	Semi-fixed 330ΩB
R127 ~ 129	RN14BK2E1000F	Metal film 100Ω ± 1% 1/4W	VR102	R01-0501-05	Variable with "VARI" switch 300ΩB
R130	RN14BK2E10ROF	Metal film 10Ω ± 1% 1/4W	VR103	R12-0501-05	Semi-fixed 100ΩB
R131, R132	RD14BB2E470J	Carbon 47Ω ± 5% 1/4W	VR104	R01-1505-05	Variable with "POSITION" switch 1kΩB
R133,134	RD14BB2E472J	Carbon 4.7kΩ ± 5% 1/4W	VR105	R12-1003-05	Semi-fixed 2.2kΩB
R135	RN14BK2E1500F	Metal film 150Ω ± 1% 1/4W	VR106	R12-0527-05	Semi-fixed 330ΩB
R136	RD14BB2E471J	Carbon 470Ω ± 5% 1/4W	VR107	R01-0501-05	Variable with "VARI" switch 300ΩB
R137,138	RD14BB2E221J	Carbon 220Ω ± 5% 1/4W	VR108	R12-0501-05	Semi-fixed 100ΩB
R139,140	RN14BK2E3901F	Metal film 3.9kΩ ± 1% 1/4W	VR109	R01-1505-05	Variable with "POSITION" switch 1kΩB
R141	RN14BK2E1200F	Metal film 120Ω ± 1% 1/4W	VR110,111	R12-0502-05	Semi-fixed 100ΩB
R142,143	RD14BB2E101J	Carbon 100Ω ± 5% 1/4W	VR112	R12-1003-05	Semi-fixed 2.2kΩB
R144,145	RD14BB2E332J	Carbon 3.3kΩ ± 5% 1/4W	VR113	R12-2020-05	Semi-fixed 6.8kΩB
R146 ~ 149	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	VR117,118	R12-0502-05	Semi fixed 100ΩB
R150	RD14BB2E560J	Carbon 56Ω ± 5% 1/4W	CAPACITOR		
R151	RD14BB2E472J	Carbon 4.7kΩ ± 5% 1/4W	C101	C91-0501-05	Metalized film 0.047μF ± 10% 630WV
R152	RD14BB1E222J	Carbon 2.2kΩ ± 5% 1/4W	C103	CM93BD2A470J	Mica 47pF ± 5% 100WV
R153,154	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	C104	CC45CH2H020C	Ceramic 2pF ± 0.25pF500WV
R155,156	RN14BK2E5600F	Metal film 560Ω ± 1% 1/4W	C105	CN93BD2A151J	Mica 150pF ± 5% 100WV
R157	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	C106	C91-0502-05	Metalized film 0.01μF ± 10% 630WV
R158	RD14BB2E681J	Carbon 680Ω ± 5% 1/4W	C107,108	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R159	RD14BB2E101J	Carbon 100Ω ± 5% 1/4W	C110,112	CE04W1A101	Electrolytic 100μF 10WV
R160,161	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	C114	C91-0501-05	Metalized film 0.047μF ± 10% 630WV
R162	RN14BK2H9003F	Metal film 900kΩ ± 1% 1/2W	C115	C91-0502-05	Metalized film 0.01μF ± 10% 630WV
R163	RN14BK2E1113F	Metal film 111kΩ ± 1% 1/4W	C117	CM93BD2A470J	Mica 47pF ± 5% 100WV
R164	RN14BK2H9903F	Metal film 990kΩ ± 1% 1/2W	C118	CC45CH2H020C	Ceramic 2pF ± 0.25pF500WV
R165	RN14BK2E1012F	Metal film 10.1kΩ ± 1% 1/4W	C119	CM93BD2A151J	Mica 150pF ± 5% 100WV
R166	RN14BK2E4021F	Metal film 4.02kΩ ± 1% 1/4W	C120 ~ 122	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R167	RN14BK2H1004F	Metal film 1MΩ ± 1% 1/2W	C123	CE04W1A101	Electrolytic 100μF 10WV
R168	RD14BB2E104J	Carbon 100kΩ ± 5% 1/4W	C125,126	CE04W1A101	Electrolytic 100μF 10WV
R169 ~ 176	RD14CB2E220J	Carbon 22Ω ± 5% 1/4W	C127	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R177,178	RN14BK2E3901F	Metal film 3.9Ω ± 1% 1/4W	C128	CE04W1C221	Electrolytic 220μF 16WV
R179	RD14CB2E681J	Carbon 680Ω ± 5% 1/4W	C129,130	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R180	RN14BK2E2701F	Metal film 2.7kΩ ± 1% 1/4W	C131	CE04W1A101	Electrolytic 100μF 10WV
R181	RN14BK2E3301F	Metal film 3.3kΩ ± 1% 1/4W	C132	CC45CH1H150J	Ceramic 15pF ± 5% 50WV
R182	RN14BK2E2201F	Metal film 2.2kΩ ± 1% 1/4W	C133	CC45CH1H220J	Ceramic 22pF ± 5% 50WV
R183	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W	C135	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R184	RN14BK2E1300F	Metal film 130Ω ± 1% 1/4W	C136	CC45CH1H121J	Ceramic 120pF ± 5% 50WV
R186	RN14BK2E69R8F	Metal film 69.8Ω ± 1% 1/4W	C137	CC45CH1H150J	Ceramic 15pF ± 5% 50WV
R187 ~ 189	RN14BK2E1000F	Metal film 100Ω ± 1% 1/4W	C138	CC45CH1H220J	Ceramic 22pF ± 5% 50WV
R190	RN14BK2E10ROF	Metal film 10Ω ± 1% 1/4W	C140	CC45CH1H050C	Ceramic 5pF ± 0.25pF50WV
R191, R192	RD14BB2E470J	Carbon 47Ω ± 5% 1/4W	C141	CC45CH1H121J	Ceramic 120pF ± 5% 50WV
R193,194	RD14BB2E472J	Carbon 4.7kΩ ± 5% 1/4W	C142,143	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV
R195	RN14BK2E1500F	Metal film 150Ω ± 1% 1/4W	C144	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R196	RD14BB2E471J	Carbon 470Ω ± 5% 1/4W	C146	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV
R197,198	RD14BB2E221J	Carbon 220Ω ± 5% 1/4W	C147	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80%
R199,200	RN14BK2E3901F	Metal film 3.9kΩ ± 5% 1/4W			
R201	RD14BB2E820J	Carbon 82Ω ± 5% 1/4W			
R202,203	RD14BB2E470J	Carbon 47Ω ± 5% 1/4W			
R204,205	RD14BB2E332J	Carbon 3.3kΩ ± 5% 1/4W			
R206 ~ 209	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W			
R210	RD14BB2E470J	Carbon 47Ω ± 5% 1/4W			
R211,212	RD14BB2E392J	Carbon 3.9kΩ ± 5% 1/4W			
R213,214	RD14BB2E221J	Carbon 220Ω ± 5% 1/4W			
R215,216	RN14BK2E5600F	Metal film 560Ω ± 1% 1/4W			
R217,218	RD14BB2E391J	Carbon 390Ω ± 5% 1/4W			
R219,220	RD14BB2E102J	Carbon 1kΩ ± 5% 1/4W			
R221	RD14BB2E221J	Carbon 220Ω ± 5% 1/4W			
R222	RD14BB2E102J	Carbon 1kΩ ± 5% 1/4W			
R223	RD14BB2E220J	Carbon 22Ω ± 5% 1/4W			
R224,225	RN14BK2E2700F	Metal film 270Ω ± 1% 1/4W			

PARTS LIST

VERTICAL OUTPUT AMPLIFIER (X73-1220-05)

Ref. No.	Parts No.	Description	Ref. No.	Parts No.	Description
RESISTOR					
C148	CM93BD2A331J	Mica 330pF -20% 12WV	R401,402	RN14BK2E91ROF	Metal film 91Ω ±1% 1/4W
C149,150	CC45CH2H020C	Ceramic 2pF ±5% 100WV	R403,404	RD14BB2E220J	Carbon 22Ω ±5% 1/4W
C151	CM93BD2A331J	Mica 330pF ±5% 100WV	R405	RD14BB2E221J	Carbon 220Ω ±5% 1/4W
C154	CC45CH1H220J	Ceramic 22pF ±5% 50WV	R406,407	RD14BB2E222J	Carbon 2.2kΩ ±5% 1/4W
C155	CC45CH1H150J	Ceramic 15pF ±5% 50WV	R408	RD14BB2E221J	Carbon 220Ω ±5% 1/4W
C156 ~ 159	CC45CH1H100D	Ceramic 10pF ±0.5pF 50WV	R409,410	RD14BB2E220J	Carbon 22Ω ±5% 1/4W
C160,161	CC45CH1H330J	Ceramic 33pF ±5% 50WV	R411	RD14BB2E100J	Carbon 10Ω ±5% 1/4W
TC101	C05-0065-05	Ceramic trimmer 6pF	R412,413	RD14BB2E391J	Carbon 390Ω ±5% 1/4W
TC102	C05-0066-05	Ceramic trimmer 10pF	R414 ~ 417	RD14BB2E220J	Carbon 22Ω ±5% 1/4W
TC103	C05-0065-05	Ceramic trimmer 6pF	R418,419	RD14BB2E222J	Carbon 2.2kΩ ±5% 1/4W
TC104	C05-0066-05	Ceramic trimmer 10pF	R420,421	RD14BB2E152J	Carbon 1.5kΩ ±5% 1/4W
TC105,106	C05-0065-05	Ceramic trimmer 6pF	R422,423	RN14BK2E4701F	Metal film 4.7kΩ ±1% 1/4W
TC107	C05-0066-05	Ceramic trimmer 10pF	R424,425	RD14BB2E1R5J	Carbon 1.5Ω ±5% 1/4W
TC108	C05-0065-05	Ceramic trimmer 6pF	R426,427	RD14BB2E220J	Carbon 22Ω ±5% 1/4W
TC109	C05-0066-05	Ceramic trimmer 10pF	R428,429	RN14BK2E7502F	Metal film 75kΩ ±1% 1/4W
TC110	C05-0065-05	Ceramic trimmer 6pF	R430,431	RD14BB2E101J	Carbon 100Ω ±5% 1/4W
TC111,112	C05-0066-05	Ceramic trimmer 10pF	R432,433	RD14BB2E100J	Carbon 10Ω ±5% 1/4W
TC113	C05-0401-05	Ceramic trimmer 20pF	R444 ~ 447	RD14BB2E101J	Carbon 100Ω ±5% 1/4W
SEMICONDUCTOR					
D101 ~ 108		Diode, silicon, small signal 1S1587	R448,449	RD14BB2E220J	Carbon 22Ω ±5% 1/4W
D109,		Diode, silicon, small signal 1S1555	R450,451	RD14BB2E222J	Carbon 2.2Ω ±5% 1/4W
111 ~ 114			R452	RD14BB2E681J	Carbon 680Ω ±5% 1/4W
116,117			R453	RD14BB2E181J	Carbon 180Ω ±5% 1/4W
119 ~ 121			R454	RD14BB2E101J	Carbon 100Ω ±5% 1/4W
D122,123		Diode, silicon, small signal 1S1587	R456	RD14BB2E681J	Carbon 680Ω ±5% 1/4W
D124 ~ 127		Diode, germanium 1N60	R457	RD14BB2E393J	Carbon 33kΩ ±5% 1/4W
Q101		FET 2SK30A(O)	R458	RD14BB2E152J	Carbon 1.5kΩ ±5% 1/4W
Q102		Dual FET 2SK228T-2 & 3	R459,460	RD14BB2E393J	Carbon 39kΩ ±5% 1/4W
Q103 ~ 106		Transistor, NPN silicon 2SC535(B)	R461	RD14BB2E333J	Carbon 33kΩ ±5% 1/4W
Q107,108		Transistor, PNP silicon 2SA838(C)	R463	RD14BB2E220J	Carbon 22Ω ±5% 1/4W
Q109,110		Transistor, NPN silicon 2SC535(B)	R466	RD14BB2E102J	Carbon 1kΩ ±5% 1/4W
Q111		FET 2SK30A(O)	R467	RD14BB2E513J	Carbon 51kΩ ±5% 1/4W
Q112		Dual FET 2SK228T-2 & 3	R471,472	RD14BB2E470J	Carbon 47Ω ±5% 1/4W
Q113 ~ 116		Transistor, NPN silicon 2SC535(B)	R476	RD14BB2E112J	Carbon 1.1kΩ ±5% 1/4W
Q117,118		Transistor, PNP silicon 2SA838(C)	R477,478	RD14BB2E181J	Carbon 180Ω ±5% 1/4W
Q119 ~ 122		Transistor, NPN silicon 2SC535(B)	VR401	R12-0511-05	Semi-fixed 220ΩB
Q123,124		Transistor, PNP silicon 2SA844(D)	VR402	R12-3004-05	Semi-fixed 47kΩB
Q125,126		Transistor, NPN silicon 2SC458(C)	VR404	R12-5018-05	Semi-fixed 220kΩB
Q127		Transistor, PNP silicon 2SA844(D)	VR405	R12-1002-05	Semi-fixed 1kΩB
IC101,102		IC, Linear HA1127	CAPACITOR		
IC103		IC, Digital SN7400N	C401,402	C90-0298-05	Ceramic semi-conductor 0.1μF +80% -20% 12WV
IC104		IC, Digital SN7472N	C403	CE04W1A331M	Electrolytic 330μF 10WV
MISCELLANEOUS					
—	E29-0503-05	Terminal x 2 (Fluorine)	C407	CK45D1H222M	Ceramic 2200pF ±20% 50WV
—	E29-0504-05	Terminal x 10 (Fluorine)	C408	CK45D1H103M	Ceramic 0.01μF ±20% 50WV
J5	E31-0658-05	Lead wire with connector	C409	CC45CH1H100D	Ceramic 10pF ±0.5pF 50WV
P101	E40-0802-05	Connector 8P	C410	CC45CH1H150J	Ceramic 15pF ±5% 50WV
P102	E40-0701-05	Connector 7P	C411	CE04W1E221	Electrolytic 220μF 25WV
—	F10-1510-04	Shield plate	C412	CE04W1C101	Electrolytic 100μF 16WV
—	F11-0147-24	Shield case	C413	C90-0298-05	Ceramic semi-conductor 0.1μF +80% -20% 12WV
—	F11-0910-13	Shield case	C414	CE04W1C470	Electrolytic 47μF 16WV
—	J25-2886-13	Printed circuit board	C415	CK45D1H103M	Ceramic 0.01μF ±20% 50WV
L101,102	L40-2201-03	Ferri inductor 22μH	C416	CK45D2H103M	Ceramic 0.01μF ±20% 500WV
TH101,102		Thermister SDT-100	C417,418	CC45CH2H010C	Ceramic 1pF ±0.25pF 500WV
—	R92-0150-05	Jumper wire, resistor type	C423,424	CC45SL1H121J	Ceramic 120pF ±5% 50WV
S101,102	S32-4007-05	Lever switch	C428,429	CK45D2H103M	Ceramic 0.01μF ±20% 500WV
S103,104	S03-3501-05	Rotary switch	C430	C90-0298-05	Ceramic semi-conductor 0.1μF +80% -20% 12WV
S105	S40-2502-05	Pushbutton switch	C431	CK45D1H103M	Ceramic 0.01μF ±20% 50WV
S106	S37-2005-05	Lever switch	C432	C90-0298-05	Ceramic semi-conductor 0.1μF +80% -20% 12WV
			C433	CE04W1A101	Electrolytic 100μF 10WV
			C434	CE04W1E221	Electrolytic 220μF 25WV
			C435	C90-0298-05	Ceramic semi-conductor 0.1μF +80% -20% 12WV

PARTS LIST

Ref. No.	Parts No.	Description				Ref. No.	Parts No.	Description			
C437	CC45SL1H820J	Ceramic	82pF	± 5%	50WV	R36	RD14BB2E822J	Carbon	8.2kΩ	± 5%	1/4W
C439	CC45SL1H221J	Ceramic	220pF	± 5%	50WV	R37	RD14BB2E682J	Carbon	6.8kΩ	± 5%	1/4W
C443,444	CK45B2H102K	Ceramic	1000pF	± 10%	500WV	R38	RD14BB2E103J	Carbon	10kΩ	± 5%	1/4W
TC402,403	C05-0066-05	Ceramic trimmer	10pF			R39	RD14BB2E682J	Carbon	6.8kΩ	± 5%	1/4W
SEMICONDUCTOR											
D401,402		Diode, silicon	1S1587			R40	RD14BB2E103J	Carbon	10kΩ	± 5%	1/4W
D403		Diode, zener	WZ-130			R41	RD14BB2E153J	Carbon	15kΩ	± 5%	1/4W
D404		Diode, zener	WZ-050			R42	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W
D405,406		Diode, silicon	1S1555			R43	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
D407		Diode, zener	WZ-050			R44	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W
D408,409		Diode, silicon	1S1587			R45	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
Q401 ~ Q404		Transistor, NPN silicon	2SC535-(B)			R46	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W
Q405 ~ 409		Transistor, NPN silicon	2SC458-(C)			R47	RD14BB2E102J	Carbon	1kΩ	± 5%	1/4W
Q410,411		Transistor, NPN silicon	2SC1628-(Y)			R48	RD14BB2E185J	Carbon	1.8MΩ	± 5%	1/4W
Q412,413		Transistor, PNP silicon	2SA818-(Y)			R49	RD14BB2E224J	Carbon	220kΩ	± 5%	1/4W
Q418,419		Transistor, NPN silicon	2SC458-(C)			R50 ~ 52	RD14BB2E104J	Carbon	100kΩ	± 5%	1/4W
MISCELLANEOUS											
—	E23-0047-04	Terminal				R53	RD14BB2E205J	Carbon	2MΩ	± 5%	1/4W
J401,402	E40-0806-05	Connector				R55	RD14BB2E123J	Carbon	12kΩ	± 5%	1/4W
—	F01-0821-04	Heat sink x 2				R56	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W
—	J32-0122-04	Hexagon boss x 2				R57	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
—	J21-2892-04	Bracket (P.C. board)				R58	RD14BB2E391J	Carbon	390Ω	± 5%	1/4W
—	J25-2808-34	Printed circuit board				R59	RD14BB2E220J	Carbon	22Ω	± 5%	1/4W
L401	L40-4701-03	Ferri-inductor	47μH			R60	RD14BB2E103J	Carbon	10kΩ	± 5%	1/4W
L406	L40-2201-03	Ferri-inductor	22μH			R61	RD14BB2E222J	Carbon	2.2kΩ	± 5%	1/4W
TH401 ~ 403		Thermistor	SDT-100			R63	RD14BB2E153J	Carbon	15kΩ	± 5%	1/4W
SWEEP (X74-1190-01)											
Ref. No.	Parts No.	Description				Ref. No.	Parts No.	Description			
RESISTOR											
R1	RD14BB2E562J	Carbon	5.6kΩ	± 5%	1/4W	R87	RD14BB2E223J	Carbon	22kΩ	± 5%	1/4W
R2	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W	R88	RD14BB2E681J	Carbon	680Ω	± 5%	1/4W
R3	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W	R89,90	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R4	RD14BB2E104J	Carbon	100kΩ	± 5%	1/4W	R91	RS14GB3D472G	Metal oxide film	4.7kΩ	± 2%	2W
R5	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W	R92	RS14GB3D512G	Metal oxide film	5.1kΩ	± 2%	2W
R6,7	RD14BB2E563J	Carbon	56kΩ	± 5%	1/4W	R93	RS14GB3A393J	Metal oxide film	39kΩ	± 5%	1W
R8	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W	R94,95	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R9	RD14BB2E470J	Carbon	47Ω	± 5%	1/4W	R96	RD14BB2E821J	Carbon	820Ω	± 5%	1/4W
R11	RD14BB2E471J	Carbon	470Ω	± 5%	1/4W	R97	RD14BB2E183J	Carbon	18kΩ	± 5%	1/4W
R12	RD14BB2E223J	Carbon	22kΩ	± 5%	1/4W	R98	RD14BB2E103J	Carbon	10kΩ	± 5%	1/4W
R13	RD14BB2E104J	Carbon	100kΩ	± 5%	1/4W	R99	RD14BB2E223J	Carbon	22kΩ	± 5%	1/4W
R14	RD14BB2E471J	Carbon	470Ω	± 5%	1/4W	R100	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R15	RD14BB2E223J	Carbon	22kΩ	± 5%	1/4W	R101	RD14BB2E272J	Carbon	2.7kΩ	± 5%	1/4W
R16,17	RD14BB2E104J	Carbon	100kΩ	± 5%	1/4W	R102	RD14BB2E182J	Carbon	1.8kΩ	± 5%	1/4W
R18	RD14BB2E561J	Carbon	560Ω	± 5%	1/4W	R103	RD14BB2E393J	Carbon	39kΩ	± 5%	1/4W
R19	RD14BB2E102J	Carbon	1kΩ	± 5%	1/4W	R104	RD14BB2E562J	Carbon	5.6kΩ	± 5%	1/4W
R20	RD14BB2E332J	Carbon	3.3kΩ	± 5%	1/4W	R105	RD14BB2E183J	Carbon	18kΩ	± 5%	1/4W
R21	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W	R111	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R22	RD14BB2E332J	Carbon	3.3kΩ	± 5%	1/4W	R112	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W
R23	RD14BB2E102J	Carbon	1kΩ	± 5%	1/4W	R113	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R25	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W	R114	RD14BB2E152J	Carbon	1.5kΩ	± 5%	1/4W
R26	RN14BK2E1003F	Metal film	100kΩ	± 1%	1/4W	R115,116	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R27	R92-0709-05	Metal film	3MΩ	± 1%	1/4W	R117,118	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W
R28	RN14BK2E1003F	Metal film	100kΩ	± 1%	1/4W	R119	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W
R29	RN14BK2E3003F	Metal film	300kΩ	± 1%	1/4W	R120	RD14BB2E473J	Carbon	47kΩ	± 5%	1/4W
R30	RN14BK2H5003F	Metal film	500kΩ	± 1%	1/2W	R121	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W
R31	RN14BK2H1004F	Metal film	100kΩ	± 1%	1/2W	R122	RD14BB2E183J	Carbon	18kΩ	± 5%	1/4W
R32	RD14BB2E104J	Carbon	100kΩ	± 5%	1/4W	R123	RD14BB2E822J	Carbon	8.2kΩ	± 5%	1/4W
R33	RD14BB2E473J	Carbon	47kΩ	± 5%	1/4W	R124	RD14BB2E472J	Carbon	4.7kΩ	± 5%	1/4W
R34	RD14BB2E683J	Carbon	68kΩ	± 5%	1/4W	R131	RD14BB2E221J	Carbon	220Ω	± 5%	1/4W
R35	RD14BB2E101J	Carbon	100Ω	± 5%	1/4W	R138	RD14BB2E221J	Carbon	220Ω	± 5%	1/4W

PARTS LIST

Ref. No.	Parts No.	Description	Ref. No.	Parts No.	Description
R139,140	RN14BK2E4701F	Metal film 4.7kΩ ± 1% 1/4W	C58	CC45SL1H050C	Ceramic 5pF ± 0.5pF 50WV
R149	RD14BB2E822J	Carbon 8.2kΩ ± 5% 1/4W	C59	CC45SL1H221J	Ceramic 220pF ± 5% 50WV
R150	RD14BB2E392J	Carbon 3.9kΩ ± 5% 1/4W	C60	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
R152	RD14BB2E393J	Carbon 39kΩ ± 5% 1/4W	C61,62	CC45SL1H020C	Ceramic 2pF ± 0.25pF 50WV
R153	RD14BB2E183J	Carbon 18kΩ ± 5% 1/4W	C63	CE04BW1H010M	Electrolytic 1μF ± 20% 50WV
R154	RD14BB2E561J	Carbon 560Ω ± 5% 1/4W	C64	CE04W1A101	Electrolytic 100μF 10WV
R157	RD14BB2E470J	Carbon 47Ω ± 5% 1/4W	C65	CQ93M1H222K	Mylar 2200pF ± 10% 50WV
VR1	R12-3041-05	Semi-fixed 10kΩB	C78 ~ 80	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV
VR2,3	R12-5025-05	Semi-fixed 100kΩB	C81 ~ 84	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV
VR4	R01-2501-05	Semi-fixed with switch (S2) 5kΩB	C87	CE04W1A470	Electrolytic 47μF 10WV
VR5	R12-5025-05	Semi-fixed 100kΩB	C88	CE04W1A221	Electrolytic 220μF 10WV
VR6	R12-1028-05	Semi-fixed 4.7kΩB	C89	CC45SL1H151J	Ceramic 150pF ± 5% 50WV
VR7	R12-3042-05	Semi-fixed 47kΩB	C90	CK45D1H152M	Ceramic 1500pF ± 20% 50WV
VR8	R01-4024-15	Variable with switch (S1) 50kΩB	C91	CC45SL1H471J	Ceramic 470pF ± 5% 50WV
VR9	R12-8501-05	Semi-fixed 2.2MΩB	C92	CE04BW1H010M	Electrolytic 1μF ± 20% 50WV
VR10	R12-3041-05	Semi-fixed 0kΩB	C93	CK45B1H471K	Ceramic 470pF ± 10% 50WV
VR11	R12S-1029-05	Semi-fixed 1kΩB	C94 ~ 96	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV
VR12	R12-2020-05	Semi-fixed 6.8kΩB	TC1	C05-0405-05	Ceramic trimmer 20pF
VR13,14	R12-0502-05	Semi-fixed 100ΩB	TC2	C05-0404-05	Ceramic trimmer 10pF
VR15	R12-3040-05	Semi-fixed 22kΩB	TC3,4	C05-0403-05	Ceramic trimmer 6pF
VR17,18	R12S-1029-05	Semi-fixed 1kΩB	SEMICONDUCTOR		
VR19	R12-3507-05	Semi-fixed 15kΩB	Q1 ~ 6		Transistor, NPN silicon 2SC945(P)
VR20	R12-1028-05	Semi-fixed 4.7kΩB	Q7,8		Transistor, PNP silicon 2SA733(Q)
CAPACITOR			Q9		Transistor, NPN silicon 2SC945(P)
C1,2	CQ93M1H682K	Mylar 6800pF ± 10% 50WV	Q10		FET 2SK30A(O)
C3	CE04W1A101	Electrolytic 100μF 10WV	Q11		Transistor, NPN silicon 2SC945(P)
C4 ~ 6	CE04W1H010	Electrolytic 1μF 50WV	Q12		FET 2SK30A(O)
C7,8	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV	Q13		Transistor, NPN silicon 2SC945(P)
C9	CC45CH1H330J	Ceramic 33pF ± 5% 50WV	Q14		FET 2SK185-2-M
C10	C90-0320-05	Metalized film 0.47μF ± 1%	Q15		FET 2SK30A(O)
C11	C90-0321-05	Metalized film 0.0047μF ± 1%	Q16 ~ 19		Transistor, NPN silicon 2SC945(P)
C12	CC45CH1H330J	Ceramic 33pF ± 5% 50WV	Q20		Transistor, NPN silicon 2SC535(C)
C13	CC45CH1H100D	Ceramic 10pF ± 0.5pF 50WV	Q21,22		Transistor, NPN silicon 2SC945(P)
C14	CS15E1VR33M	Tantalum 0.33μF ± 20% 35WV	Q23,24		Transistor, NPN silicon 2SC1507
C15	CQ93M1H333K	Mylar 0.033μF ± 10% 50WV	Q25 ~ 29		Transistor, NPN silicon 2SC945(P)
C16	CK45D1H102M	Ceramic 1000pF ± 20% 50WV	Q31		Transistor, NPN silicon 2SC945(P)
C17	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV	IC1		IC, Digital SN74H00N
C18	CC45CH1H180J	Ceramic 18pF ± 5% 50WV	IC2		IC, Digital SN74H72N
C19,20	CQ93M1H152K	Mylar 1500pF ± 10% 50WV	IC3		IC, Digital NJM555D
C21	CK45B1H681K	Ceramic 680pF ± 10% 50WV	IC4		IC, Digital SN7400N
C22	CC45SL1H151J	Ceramic 150pF ± 5% 50WV	IC5		IC, Digital RC733T
C23	CC45SL2H100D	Ceramic 10pF ± 0.5pF 50WV	IC6 ~ 10		IC, Digital SN74LS00N
C24	CQ93M1H153K	Mylar 0.015μF ± 10% 50WV	IC12		IC, Digital SN74LS00N
C25	CC45SL2H101J	Ceramic 100pF ± 5% 50WV	IC13		IC, Digital SN74H72N
C26	CC45SL1H150J	Ceramic 15pF ± 5% 50WV	D1		Diode, germanium 1N60
C27	CK45D2H332M	Ceramic 3300pF ± 20% 50WV	D2 ~ 4		Diode, silicon 1S1555
C28,29	CE04BW1H010M	Electrolytic 1μF ± 20% 50WV	D5		Diode, germanium 1N60
C30	CC45SL1H150J	Ceramic 15pF ± 5% 50WV	D6		Diode, silicon 1S1587
C31 ~ 34	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV	D7 ~ 10		Diode, silicon 1S1555
C35	CC45SL1H150J	Ceramic 15pF ± 5% 50WV	D11		Diode, germanium 1N60
C37	CC45CH1H050C	Ceramic 5pF ± 0.25pF 50WV	D15		Diode, silicon 1S1555
C38	CK45D2H102M	Ceramic 1000pF ± 20% 50WV	D16		Diode, zener YZ-030
C39	CE04W1A101	Electrolytic 100μF 10WV	D17 ~ 20		Diode, silicon 1S1555
C40,41	CE04W1C471M	Electrolytic 470μF 16WV	D22,23		Diode, silicon 1S1555
C42	CK45D1H222M	Ceramic 2200pF ± 20% 50WV	D26		Diode, silicon 1S1555
C43	CE04W1A470	Electrolytic 47μF 10WV	D28,29		Diode, silicon 1S1555
C44	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV	D30		Diode, germanium 1N60
C45	CC45SL1H470J	Ceramic 47pF ± 5% 50WV	D32 ~ 40		Diode, silicon 1S1555
C46	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV	MISCELLANEOUS		
C48	CC45SL1H100D	Ceramic 10pF ± 0.5pF	E23-0046-04		Terminal x 10
C49	CC45SL1H221J	Ceramic 220pF ± 5% 50WV	J1,2	E40-0808-05	Connector
C51	CK45D1H103M	Ceramic 0.01μF ± 20% 50WV			
C52 ~ 56	C90-0298-05	Ceramic, semi-conductor 0.1μF + 80% - 20% 12WV			
C57	CC45SL1H221J	Ceramic 220pF ± 5% 50WV			

PARTS LIST

Ref. No.	Parts No.	Description
P2	E40-0367-05	Connector 3P
P3	E40-0767-05	Connector 7P
P4	E40-0367-05	Connector 3P
P5	E40-0467-05	Connector 4P
P7	E40-0467-05	Connector 4P
P8	E40-0267-05	Connector 2P
L2	L40-4701-03	Ferri-inductor 47 μ H
L3	L40-3991-02	Ferri-inductor 3.9 μ H
L4,5	L40-1511-03	Ferri-inductor 150 μ H
L6~8	L40-4701-03	Ferri-inductor 47 μ H
L9	L40-1011-03	Ferri-inductor 100 μ H
L10	L40-3311-03	Ferri-inductor 330 μ H
L11	L40-1511-03	Ferri-inductor 150 μ H
—	J25-2866-23	Printed circuit board
S2	S29-2504-05	Rotary switch
S3	S33-2501-05	Lever switch
S4	S37-2005-05	Lever switch
S5	S32-2013-05	Lever switch
DELAY SWEEP (X74-1200-00)		
Ref. No.	Parts No.	Description
RESISTOR		
R1	RD14BB2E472J	Carbon 4.7k Ω \pm 5% 1/4W
R2	RD14BB2E103J	Carbon 10k Ω \pm 5% 1/4W
R3	RD14BB2E472J	Carbon 4.7k Ω \pm 5% 1/4W
R5	RD14BB2E224J	Carbon 220k Ω \pm 5% 1/4W
R6	RN14BK2E4701F	Metal film 4.7k Ω \pm 1% 1/4W
R7	RD14BB2E103J	Carbon 10k Ω \pm 5% 1/4W
VR1	R06-9501-05	Variable with switch (S01-1510-15) 100k Ω
CAPACITORS		
C1	CE04W1A3R3	Electrolytic 3.3 μ F 10WV
C2	C91-0542-05	Filmed 0.33 μ F
C3	CQ93M1H333K	Mylar 0.033 μ F \pm 10% 50WV
C4	CQ93M1H332K	Mylar 3300pF \pm 10% 50WV
C5	CC45SL1H221J	Ceramic 220pF \pm 5% 50WV
C6	CC45SL1H101J	Ceramic 100pF \pm 5% 50WV
C7	CE04W1A470	Electrolytic 47 μ F 10WV
C8	CK45D1H103M	Ceramic 0.01 μ F \pm 20% 50WV
C9	CK45D1H103M	Ceramic 0.01 μ F \pm 20% 50WV
SEMICONDUCTORS		
IC1		IC, Digital SN74LS123N
IC2		IC, Digital SN74H72N
D1~4		Diode, silicon 1S1555
MISCELLANEOUS		
—	E23-0047-04	Terminal
—	F11-0943-04	Shield case
—	J61-0053-05	Supporter, (PC board)
—	J25-2867-14	Printed circuit board
L1	L40-4701-03	Ferri-inductor 47 μ H
P1	E40-0269-05	Connector, 2P
P2	E40-0769-05	Connector, 7P
S1	S01-1510-15	Rotary switch


Ref. No.	Parts No.	Description
POWER SUPPLY (X68-1270-02)		
RESISTOR		
R302	R92-0746-05	Metal film 12M Ω \pm 5% 1W
R303	RC05GF2H335J	Solid 3.3M Ω \pm 5% 1/2W
R304,305	RC05GF2H226K	Solid 22M Ω \pm 10% 1/2W
R306	RC05GF2H473J	Solid 47k Ω \pm 5% 1/2W
R307	RD14BB2E683J	Carbon 68k Ω \pm 5% 1/4W
R308	RD14BB2E103J	Carbon 10k Ω \pm 5% 1/4W
R309	RD14BB2E331J	Carbon 330 Ω \pm 5% 1/4W
R310	RD14BB2E102J	Carbon 1k Ω \pm 5% 1/4W
R311	RD14BB2E104J	Carbon 100k Ω \pm 5% 1/4W
R312	RD14BB2E473J	Carbon 47k Ω \pm 5% 1/4W
R313	RD14BB2E103J	Carbon 10k Ω \pm 5% 1/4W
R314	RD14BB2E151J	Carbon 150 Ω \pm 5% 1/4W
R315	RN14BK2E1303F	Metal film 130k Ω \pm 1% 1/4W
R317	RD14BB2E101J	Carbon 100 Ω \pm 5% 1/4W
R318	RD14BB2E470J	Carbon 47 Ω \pm 5% 1/4W
R319~321	RD14BB2E101J	Carbon 100 Ω \pm 5% 1/4W
R322	RD14BB2E472J	Carbon 4.7k Ω \pm 5% 1/4W
R323	RD14BB2E331J	Carbon 330 Ω \pm 5% 1/4W
R324	RD14BB2E333J	Carbon 33k Ω \pm 5% 1/4W
R325	RD14BB2E473J	Carbon 47k Ω \pm 5% 1/4W
R326	RD14BB2E682J	Carbon 6.8k Ω \pm 5% 1/4W
R327	RD14BB2E223J	Carbon 22k Ω \pm 5% 1/4W
R328	RD14BB2E332J	Carbon 3.3k Ω \pm 5% 1/4W
R329	RD14BB2E223J	Carbon 22k Ω \pm 5% 1/4W
R330	RD14BB2E103J	Carbon 10k Ω \pm 5% 1/4W
R331~333	RD14BB2E101J	Carbon 100 Ω \pm 5% 1/4W
R334	RD14BB2E222J	Carbon 2.2k Ω \pm 5% 1/4W
R335	RD14BB2E122J	Carbon 1.2k Ω \pm 5% 1/4W
R336,337	RD14BB2E2R2J	Carbon 2.2 Ω \pm 5% 1/4W
R338	RN14BK2E4301F	Metal film 4.3k Ω \pm 1% 1/4W
R339	RN14BK2E8201F	Metal film 8.2k Ω \pm 1% 1/4W
R340	RD14BB2E471J	Carbon 470 Ω \pm 5% 1/4W
R341	RN14BK2E1502F	Metal film 15k Ω \pm 1% 1/4W
R342	RN14BK2E1202F	Metal film 12k Ω \pm 1% 1/4W
R343	RD14BB2E2R2J	Carbon 2.2 Ω \pm 5% 1/4W
R344	RN14BK2E6801F	Metal film 6.8k Ω \pm 1% 1/4W
R345	RD14BB2E682J	Carbon 6.8k Ω \pm 5% 1/4W
R346	RD14BB2E221J	Carbon 220 Ω \pm 5% 1/4W
R347	RD14BB2E222J	Carbon 2.2k Ω \pm 5% 1/4W
R348	RN14BK2E9102F	Metal film 91k Ω \pm 1% 1/4W
R349,350	RD14BB2E4R7J	Carbon 4.7 Ω \pm 5% 1/4W
R351	RD14BB2E102J	Carbon 1k Ω \pm 5% 1/4W
R352	RD14BB2E104J	Carbon 100k Ω \pm 5% 1/4W
R353	RS14GB3D511J	Metal oxide 510 Ω \pm 5% 2W
R354	RD14BB2E151J	Carbon 150 Ω \pm 5% 1/4W
R355	RD14BB2E223J	Carbon 22k Ω \pm 5% 1/4W
R356	RD14BB2E473J	Carbon 47k Ω \pm 5% 1/4W
R357~359	RD14BB2E102J	Carbon 1k Ω \pm 5% 1/4W
R361	RD14BB2E104J	Carbon 100k Ω \pm 5% 1/4W
R362,363	RD14BB2E473J	Carbon 47k Ω \pm 5% 1/4W
R364	RD14BB2E105J	Carbon 1M Ω \pm 5% 1/4W
R365	R92-0778-05	Metal film 7.5M Ω \pm 5% 1W
VR302	R12-3004-05	Semi-fixed 47k Ω B
VR303	R12-3042-05	Semi-fixed 47k Ω B
VR304	R12-1002-05	Semi-fixed 1k Ω B
CAPACITORS		
C304	CK45E3D102P	Ceramic 1000pF +100% -0% 2kVW
C305~308	CK45E3D103P	Ceramic 0.01 μ F +100% -0% 2kVW
C309	CK45F1H103Z	Ceramic 0.01 μ F +80% -20% 50WV
C310	CE04W1H471	Electrolytic 470 μ F 50WV
C311	CQ93M1H153K	Mylar 0.015 μ F \pm 10% 50WV
C312	C91-0472-05	Film 0.1 μ F

PARTS LIST


Ref. No.	Parts No.	Description	Ref. No.	Parts No.	Description
C313	CE04W2E3R3	Electrolytic 3.3μF 250WV	MISCELLANEOUS		
C314	CC45SL1H221J	Ceramic 220μF 50WV	P301	E40-0903-05	Connector, 9P
C315	CC45CH2H020C	Ceramic 2pF ±0.25pF 500WV	P302	E40-0403-05	Connector, 4P
C316	C90-0298-05	Ceramic, semi-conductor 0.1μF +80% -20% 12WV	P304	E40-0432-05	Connector, 4P
C317	CC45CH1H100D	Ceramic 10pF ±0.5pF 50WV	P305	E40-0532-05	Connector, 5P
C318	CK45D2H332M	Ceramic 3300pF ±20% 500WV	P306	E40-0801-05	Connector, 8P
C319 ~ 321	CK45D2H103M	Ceramic 0.01μF ±20% 500WV	P307	E40-0802-05	Connector, 8P
C322	C90-0298-05	Ceramic, semi-conductor 0.1μF +80% -20% 12WV	P308	E40-0367-05	Connector, 3P
C323	CE04W1A331	Electrolytic 330μF 10WV	P309	E40-0267-05	Connector, 2P
C324	C90-0298-05	Ceramic, semi-conductor 0.1μF +80% -20% 12WV	—	E23-0047-05	Terminal
C325	CE04W1C221	Electrolytic 220μF 16WV	—	F01-0801-04	Heat sink
C326	C90-0218-05	Electrolytic 3300μF 25WV	—	F01-0813-05	Heat sink
C327	CE04W1E222	Electrolytic 2200μF 25WV	—	F01-0825-04	Heat sink
C328	CE04W1E101	Electrolytic 100μF 25WV	—	F05-5016-05	Fuse 0.5A T
C329	CE04W1H101	Electrolytic 100μF 50WV	—	F11-0911-33	Shield case
C330	CE04W1A331	Electrolytic 330μF 10WV	—	F11-0912-04	Shield case
C331	C90-0298-05	Ceramic, semi-conductor 0.1μF +80% -20% 12WV	—	J42-0017-05	Bushing (rubber)
C332,333	CK45D2H103M	Ceramic 0.01μF ±20% 500WV	—	J13-0039-05	Fuse holder
C334	CE04W2C100	Electrolytic 10μF 160WV	—	J25-2861-33	Printed circuit board
C335	CE04W2C101	Electrolytic 100μF 160WV	—	J25-2890-04	Printed circuit board
C336	CE04W1E330	Electrolytic 33μF 25WV	—	J61-0053-05	Supporter (P.C. Board)
C337	CE04W2C100	Electrolytic 10μF 160WV	N301 ~ 303		Neon lamp NE-2
C338	CK45E3D103P	Ceramic 0.01μF +100% -0% 2kWV	—	E31-0665-05	Lead wire with connector IP (INTEND)
C339,340	C90-0298-05	Ceramic, semi-conductor 0.1μF +80% -20% 12WV	L301	L40-4711-03	Ferri-inductor 470μH
C341,342	CE04W1E100	Electrolytic 10μF 25WV	L302	L40-3391-03	Ferri-inductor 3.3μH
C343	C90-0298-05	Ceramic, semi-conductor 0.1μF +80% -20% 12WV	T301	L19-0408-05	Transformer (converter)
C344	CK45D2H103M	Ceramic 0.01μF ±20% 500WV	TH301		Thermistor SDT-1000
TC301	C05-0401-05	Ceramic trimmer 20pF	AUTO FOCUS (X68-1270-02)		
SEMICONDUCTORS			Ref. No.	Parts No.	Description
Q301		Transistor, NPN silicon 2SD401A-(K)	RESISTOR		
Q302		Transistor, NPN silicon 2SC983-(Y)	R1	RN14BK2E1101F	Metal film 1.1kΩ ±1% 1/4W
Q303		Transistor, NPN silicon 2SC945-(P)	R2 ~ 4	RD14BB2E 101J	Carbon 100Ω ±5% 1/4W
Q304		Transistor, NPN silicon 2SC1628-(Y)	R5	RD14BY2H 473J	Carbon 47kΩ ±5% 1/2W
Q305		Transistor, PNP silicon 2SA818-(Y)	R6	RD14BB2E 222J	Carbon 2.2kΩ ±5% 1/4W
Q306		Transistor, NPN silicon 2SC535-(B)	R7	RN14BK2E9101F	Metal film 9.1kΩ ±1% 1/4W
Q307,308		Transistor, NPN silicon 2SC1419-(C)	R8	RN14BK2E5102F	Metal film 51kΩ ±1% 1/4W
Q309		Transistor, PNP silicon 2SB633-(E)	R9	RN14BK2E7502F	Metal film 75kΩ ±1% 1/4W
Q310		Transistor, PNP silicon 2SB546-(A)	R10	RD14BB2E 103J	Carbon 10kΩ ±5% 1/4W
Q311		Transistor, PNP silicon 2SA733-(Q)	R11	RD14BB2E 470J	Carbon 47Ω ±5% 1/4W
Q312 ~ 316		Transistor, NPN silicon 2SC945-(P)	R12	RD14BB2E 683J	Carbon 68kΩ ±5% 1/4W
Q317		Transistor, NPN silicon 2SC1384	R13	R92-0756-05	Metal film 74MΩ ±5% 1/2W
Q318		Transistor, NPN silicon 2SA684	CAPACITOR		
D301		Diode, silicon, high voltage Y16JA	C1	CK45D2H103M	Ceramic 0.01μF ±20% 500WV
D302	W02-0401-05	High voltage rectifier block	C2	CK45D1H103M	Ceramic 0.01μF ±20% 50WV
D304 ~ 306		Diode, silicon 1S2463	C3	CC45CH2H010C	Ceramic 1pF ±0.25pF 500WV
D307		Diode, silicon 1S583	C4 ~ 6	CK45E3D103P	Ceramic 0.01μF ±100% -0% 2kWV
D308 ~ 315		Diode, silicon 1S1555	SEMICONDUCTOR		
D316		Diode, zener WZ-050	Q1		Transistor 2SA1208-(S)
D317		Diode, zener WZ-075	Q2		Transistor 2SC2910-(S)
D318		Diode, zener WZ-150	Q3		Transistor 2SC1360
D319		Diode, rectifier, bridge SIRBA40	Q4		Transistor 2SC983(Y)
D320		Diode, rectifier, bridge SIQB60	D1		Zener Diode WZ-050
D321,322		Diode, silicon 1S1555	D3		Diode 1S1555
IC301		IC, Linear RC4558T	D4,5		Diode W06C
			D6		Diode 1S583

P.C. BOARD


X73-1210-02




- Q102, 112: 2SK228T-2 & 3, Q125, 126: 2SC458 (C), Q107, 108, 117, 118: 2SA838 (C)
- Q101, 111: 2SK30A (O), Q123, 124, 127: 2SA844 (D), Q103 ~ 106, 109, 110, 113 ~ 116, 119 ~ 122: 2SC535 (B)
- IC101, 102: HA1127, IC103: SN7400N, IC104: SN7472N
- D101 ~ 108, 122, 123: 1S1587, D109, 111 ~ 114, 116, 117, 119 ~ 121: 1S1555
- D124 ~ 127: 1N60




2SK228T-2 & 3




2SC458 (C)
2SA844 (D)
2SC535 (B)



2SA838 (C)




2SK30A (O)




SN7400N
SN7472N
HA1127

P.C. BOARD


X74-1190-01



- Q1~6, 9, 11, 13, 16~19, 21, 22, 25~29, 31: 2SC945 (P), Q7, 8: 2SA733 (Q)
- Q23, 24: 2SC1507, Q10, 12, 15: 2SK30A (O)
- IC1: SN74H00N, IC2, 13: SN74H72N, IC3: NJM555D, IC4: SN7400N
- IC5: RC733T, IC6~10, 12: SN74LS00N
- D1, 5, 11, 30: 1N60, D2~4, 7~10, 15, 17~20, 22, 23, 26, 28, 29, 32~40: 1S1555
- D6: 1S1587



2SC945 (P)
2SA733 (Q)




2SC1507



SN74H00N
SN74H72N
SN74LS00N



NJM555D




RC733T




Bottom view

P.C. BOARD


X68-1270-02




- Q301: 2SD401A (K), Q302: 2SC983 (Y), Q303, 312 ~ 316: 2SC945 (P), Q304: 2SC1628 (Y)
- Q305: 2SA818 (Y), Q306: 2SC535 (B), Q307, 308: 2SC1419 (C), Q309: 2SB633 (E)
- Q310: 2SB546 (A), Q311: 2SA733 (Q), Q317: 2SC1384, Q318: 2SA684
- IC301: NJM4558T
- D301: Y16JA, D302: W02-0401-05, D304 ~ 306: 1S2463, D307: 1SS83
- D308 ~ 315, 321, 322: 1S1555, D316: WZ-050, D317: WZ-075, D318: WZ-150
- Q319: S1RBA40, D320: S1QB60




2SD401A (K)
2SB546 (A)




2SC983 (Y)




2SC1628 (Y)




2SA818 (Y)
2SC1384
2SA684



2SC1419 (C)




NJM4558T



2SB633 (E)


P.C. BOARD

X73-1220-05




Q401~404: 2SC535(B), Q405~409, 418, 419: 2SC458(C), Q410, 411: 2SC1628(Y), Q412, 413: 2SA818(Y), D401, 402, 408, 409: 1S1587, D405, 406: 1S1555, D404, 407: WZ-050, D403: WZ-130

X74-1200-00




IC1: SN74LS123N, IC2: SN74H72N, D1, 2, 3, 4: 1S1555




SN74LS123N

P.C. BOARD

X68-1270-02






















Q1: 2SA1208 (S), Q2: 2SC2910 (S), Q3: 2SC1360, Q4: 2SC983 (Y), D1: WZ-050,
D2, 4~6: 1SS83, D3: 1S1555




2SA1208 (S)
2SC2910 (S)
2SC1360

DISASSEMBLY






SCHEMATIC DIAGRAM



CS-1820



The circuit elements may be changed without notice owing to a technical innovation.

A product of
TRIO-KENWOOD CORPORATION

6-17, 3-chome, Aobadai, Meguro-ku, Tokyo 153, Japan

PRINTED IN JAPAN B51-1021-00 (T)