



Operation	Connect Oscillator to	Dummy Antenna	Input Signal Frequency	Band	Set Dial At	Trimmers
1	Converter Grid	.5 mfd.	455 Kc.	BC	600 Kc.	A, B, C, D
2	Single Turn Loop Coupled Loosely	.5 mfd.	1600 Kc.	"	1600 Kc.	F
3	Wave Magnet	.5 mfd.	1400 Kc.	"	1400 Kc.	H, G

Models 6R683-6R684-6R687R* -6R688

Chassis No. 6B06 Phono.

DIAG. N ^o	PART N ^o	DESCRIPTION	DIAG. N ^o	PART N ^o	DESCRIPTION	DIAG. N ^o	PART N ^o	DESCRIPTION	
C1	22-1241	THREE GANG VARIABLE	R3	63-579	220 OHM	1/2 W	2	59834	DETECTOR COIL ASSEM.
C2	22-828	.05 MFD	R4	63-673	8.2 MEGOHM	1/8 W	3	59835	OSCILLATOR "
C3	22-829	.05 MFD.	R5	63-589	10M OHM	1/4 W	4	95-841	1ST I.F. TRANSFORMER
C4	22-327	.02 MFD.	R6	63-605	1000 OHM	1/2 W	5	95-842	2ND I.F. "
C5	22-887	.001 MFD.	R7	63-600	2.2 MEGOHM	1/2 W	6	85-297	PHONO-RADIO SWITCH
C6	22-448	.004 MFD.	R8	63-1058	22M OHM	2 W	7	95-840	PWR. TRANS. 117V. 50-60W
C7	22-854	.0005 MFD.	R9	63-1246	VOLUME CONTROL	B	8	100-36	DIAL LIGHT 6.3 V. .25A
C8	22-830	.02 MFD	R10	63-591	22 M OHM	1/2 W			
C9	22-135	.2 MFD	R11	63-1247	TONE CONTROL				
C10	22-719	16 MFD ELECTROLYTIC	R12	63-976	15 MEGOHM	1/2 W			
C11	22-1036	14 MFD.	R13	63-597	470M OHM	1/2 W			
C12	22-1031	.005 MFD.	R14	63-655	220 M OHM	1/2 W			
			R15	63-656	270M OHM	1/2 W			
R1	63-1071	10M OHM					A		1ST I.F. TRANS. PRI.
R2	63-296	220M OHM					B		1ST I.F. " SEC.
							C		2ND I.F. " PRI.
							D		2ND I.F. " SEC.
							F		BROADCAST OSC. (ON GANG)
							G		BROADCAST ANT. (ON GANG)
							H		BROADCAST DET. (ON GANG)

